

SOLAX



X3-ULTRA

15 kW / 19.9 kW / 20 kW / 25 kW / 30 kW

10K-GLV / 15K-GLV

User Manual

Version 16.0

www.solaxpower.com



eManual in the QR code or
at www.solaxpower.com

STATEMENT

Copyright

Copyright © SolaX Power Network Technology (Zhejiang) Co., Ltd. All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of SolaX Power Network Technology (Zhejiang) Co., Ltd.

Trademarks



and other symbol or design (brand name, logo) that distinguishes the products or services offered by SolaX has been trademark protected. Any unauthorized use of the above stated trademark may infringe the trademark right.

Notice

Please note that certain products, features, and services mentioned in this document may not be within the scope of your purchase or usage. Unless otherwise specified in the contract, the contents, information, and recommendations presented in this document are provided "as is" by SolaX. We do not provide any warranties, guarantees, or representations, whether express or implied.

The content of the documents is reviewed and updated as needed. However, occasional discrepancies may occur. SolaX retains the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without prior notice.

The images included in this document are solely for illustrative purposes and may differ based on the specific product models.

For more detailed information, kindly visit the website of SolaX Power Network Technology (Zhejiang) Co., Ltd. at www.solaxpower.com.

SolaX retains all rights for the final explanation.

About This Manual

Scope of Validity

This manual is an integral part of X3-ULTRA series inverter. It describes the installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

This manual is valid for the following inverter models:

- X3-ULT-15K
- X3-ULT-15KP
- X3-ULT-19.9K (Applicable to Italy)
- X3-ULT-20K
- X3-ULT-20KP
- X3-ULT-25K
- X3-ULT-30K
- X3-ULT-10K-GLV
- X3-ULT-15K-GLV
- X3-ULT-25KW (Applicable to Belgium)

Model Description

X3-ULT-15K-GLV

1

2

3

Item	Meaning	Description
1	Product family name	"X3-ULTRA" refers to the energy storage inverter that supports grid connection of photovoltaic system.
2	Power	"15K" refers to the rated output power of 15 kW.
3	Voltage	"GLV": low voltage grid (3P3W, 230 V/133 V, 220 V/127 V).

Target Group

The installation, maintenance and grid-related setting can only be performed by qualified personnel who:

- Are licensed and/or satisfy state and local jurisdiction regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
 DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION!	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE!	Provides tips for the optimal operation of the product.

Change History

Version 16 (2026-07-30)

Updated ["15.6 Application of Parallel Function"](#) to exclude GLV models from the parallel support table, add notes on GLV incompatibility and actual device capacity, and replaced all instances of "X3-PBOX" with "X3-EPS Parallel Box G2" throughout the document.

Added ["15.1 Installation Video"](#).

Added a 63 A manual changeover switch for Australia and New Zealand to ["6.2 Scope of Delivery"](#)

Updated the wiring diagram for Australia and New Zealand and corrected other mistakes in all wiring diagrams in ["2.5.2 Application Schemes"](#)

Updated the file name "upgrade" to "update" in ["Upgrading preparation"](#)

Updated the logo of SolaX

Version 15 (2026-01-21)

Updated the dongle and added note in ["6.2 Scope of Delivery"](#), ["8.1.2 Cable Connections of Inverter"](#), and ["13.1 Disassembling the Inverter"](#), clarifying that users should refer to the actual dongle and its documentation.

Deleted ["Monitoring Connection"](#)

Updated the rated AC current value to max AC current (50 A) in ["14 Technical Data"](#).

Updated the dongle installation steps in the section of monitoring connection in ["15.6 Application of Parallel Function"](#)

Deleted the notice for the home version of the Smart EV Charger and deleted the charging mode description, added a wiring diagram for Smart EV Charger G2 to ["15.3 Application of EV Charger"](#)

Version 14 (2025-09-15)

Added an H2.5 hex bit for the screwdriver and included a corresponding note to ["5.2 Tools Requirement"](#)

Added a note for the Allen key to ["6.2 Scope of Delivery"](#)

Updated the tool and added a safety notice to ["8.3 AC Connection"](#)

Modified the text of "PVRT" to "FVRT" in ["10.7.2 Advanced Setting"](#)

Version 13 (2025-07-02)

Modified the diagram for Australia in ["2.5.2 Application Schemes"](#)

Added the protective class and earth fault troubleshooting

Added two communication connectors in the packing list

Added a notice of "When the voltage is below 180V, the inverter will limit the battery current to less than 20A." in ["14 Technical Data"](#)

Modified the UI from Adapterbox G2 and DataHub to Heatpump Ctrl and Smart Ctrl in ["15.2 Application of Adapter Box G2"](#) and ["15.4 Application of DataHub"](#)

Updated the gross weight in ["4 Transportation and Storage"](#) and net weight in ["14 Technical Data"](#)

Version 12 (2025-05-23)

Modified the icon of ["Table 10-1 Definition of indicators"](#)

Version 11 (2025-05-13)

Added ["Shut Down"](#).

Updated ["Table 15-6 Maximum number of inverter paralleled"](#);

Modified "X3-EPS Parallel BOX" to "X3-EPS Parallel Box G2";

Version 10 (2025-01-02)

Updated ["Setting Main Breaker Limit"](#);

Updated ["2.5.1 Circuit Diagram"](#);

Updated ["Setting Peak shaving mode"](#);

Version 09 (2024-10-10)

Added model X3-ULT-10K-GLV, X3-ULT-15K-GLV and X3-ULT-25KW;

Updated "10.7 Setting". (Supported SolaXMeter, added bias power, added battery heat level) ;

Updated "10.5 System Status". (Added pack status);

Updated "10.4 Mode Select". (Added Charge/discharge power of TOU);

Added "2.7.7 SmartSchedule Mode";

Updated "12.2 Troubleshooting".

Version 08 (2024-08-23)

Added dual-battery connection interface.

The range limit for the Main Breaker Limit setting has been adjusted to reach a maximum of 1000A.

Support for on-grid battery heating functionality was implemented.

The battery configuration has been expanded to include the 51 series battery, with a note that the T58 may not be compatible in some areas, and an explanation for the battery paralleling box has been added.

Version 07 (2024-07-10)

Added wiring method with a cable cover.

Version 06 (2024-06-05)

Ripple control function added parallel program diagram.

Wi-Fi configuration interface updated.

Parameter DI * 5, DO * 2 is changed to DI * 2, DO * 1.

Change the presentation of battery configuration program, startup voltage 180 to 120.

Version 06 (2024-04-28)

Modified company address.

Added a note below the "Max. input current" section in the technical parameters: "Maximum output current for a single MPPT string: 18A when both strings are connected; 20A when only one string is connected."

Corrected the pin connections for Datahub/heat pump on the inverter side.

Changed the address for the heat pump to 96 on page 149.

Removed the color of the inverter body.

Added relevant content regarding arc pulling.

Version 05 (2024-04-02)

Added (xxxx for VDE 4105);

Version 04 (2024-03-28)

Removed heat shrink tubing from the PE terminals;

Modified PV terminals, added dust caps to the accessory package;

Added section 8.1.2 Cable Connections of Inverter;

Inserted corresponding text for accessory package numbers;

Updated contact information for Turkey and Italy; removed personal contact information and emails for South Africa and Pakistan;

Optimized diagrams for setting power factor and Pu function sections;

Optimized connection diagrams in the document, added connection points at joints;

Changed "Max. inverter backfeed current to the array [A]" to 0;

Modified "X3-Parallel EPS BOX" to "X3-EPS Parallel BOX".

Version 03 (2024-01-30)

Added model 20KP; Removed "Coming soon" for BMS-Parallel Box-II G2 on P52; Removed UKCA; Updated contact information;

Changed the torque for communication port connectors to 0.4;

Changed the electricity meter to CT in the diagram on P151.

Version 02 (2023-12-28)

Changed the plug of the BAT end (updated the diagram);

Added supplementary explanation for Idle status on P12; Added electric shock prevention warning on P45 (required connection of Grid and EPS terminals before device power-on);

Adjusted cover logo, added illustrations; Changed PV and PE cables; Corrected pin connection for system switch;

Added step 4 EPS debugging on section 8.2; Added notice (used special tools for disassembly);

Changed AC terminals; Changed the cap of the dongle; Adjusted the order of some chapters;

Updated the QR code;

Added TOU mode; Added model 15KP; Changed parallel cabinet to X3-Parallel EPS BOX; Added lockable DC switch on; Updated accessory package, updated tools requirement.

Version 01 (2023-11-07)

Corrected the error code of "INterComFault" to "IE25"; Changed Wi-Fi-p to Wi-Fi+LAN; Modified the cover product image; Added a comparison of power output between regular EPS mode and Super-Backup mode.

Version 00 (2023-10-11)

Initial release

Table of Contents

1	Safety	1
1.1	General Safety	1
1.2	Safety Instructions of PV, Inverter and Grid	1
1.2.1	Safety Instructions of PV	2
1.2.2	Safety Instructions of Inverter	2
1.2.3	Safety Instructions of Utility Grid	3
2	Product Overview	4
2.1	System Description	4
2.2	Appearance	4
2.3	Supported Power Grid	5
2.4	Symbols on the Label and Inverter	7
2.5	Working Principle	8
2.5.1	Circuit Diagram	8
2.5.2	Application Schemes	9
2.6	Working State	12
2.7	Working Mode	13
2.7.1	Self-use Mode (Priority: Loads > Battery > Grid)	13
2.7.2	Feed-in Priority (Priority: Loads > Grid > Battery)	15
2.7.3	Backup Mode (Priority: Loads > Battery > Grid)	16
2.7.4	Peak Shaving Mode	18
2.7.5	TOU Mode	19
2.7.6	EPS Mode (Priority: Loads > Battery)	20
2.7.7	Smart Schedule Mode	21
2.7.8	Manual Mode	21
2.7.9	Export Control Function	22
3	System Overview	23
4	Transportation and Storage	26
5	Preparation Before Installation	27
5.1	Selection of Installation Location	27
5.1.1	Environment Requirement	27
5.1.2	Installation Carrier Requirement	29
5.1.3	Clearance Requirement	30
5.2	Tools Requirement	31
5.3	Additionally Required Materials	32

6	Unpacking and Inspection	34
6.1	Unpacking.....	34
6.2	Scope of Delivery.....	35
7	Mechanical Installation	38
7.1	Dimensions for Mounting	39
7.2	Installation Procedures.....	40
8	Electrical Connection	43
8.1	Overview of Electrical Connection	43
8.1.1	Terminals and Ports of Inverter	43
8.1.2	Cable Connections of Inverter.....	45
8.2	PE Connection	48
8.3	AC Connection.....	50
8.4	PV Connection	54
8.5	Battery Power Cable Connection.....	59
8.6	COM 1 Communication Connection	66
8.6.1	Pin Assignment of COM 1 Port.....	66
8.6.2	Parallel Communication Connection.....	67
8.6.3	BMS Communication Connection	70
8.6.4	RS485 Communication Connection	72
8.6.5	DRM Connection (Applicable to AS/NZS 4777)	73
8.7	COM 2 Communication Connection.....	75
8.7.1	Pin Assignment of COM 2 Port	75
8.7.2	Meter/CT Connection.....	76
8.7.3	Ripple Control Communication Connection	84
8.7.4	DIO Communication Connection	86
9	System Commissioning	89
9.1	Checking before Power-on	89
9.2	Powering on the System.....	89
9.3	Operation of lockable DC Switch	90
10	Operation on LCD.....	93
10.1	Introduction of Control Panel.....	93
10.2	Introduction of Menu Interface	94
10.3	System ON/OFF.....	97
10.4	Mode Select	97
10.5	System Status	100
10.6	History Data.....	102
10.7	Setting	103

10.7.1	User Setting.....	104
10.7.2	Advanced Setting	110
10.8	About.....	131
11	Operation on SolaXCloud	132
11.1	Introduction of SolaXCloud App.....	132
11.2	Operation Guide on SolaXCloud App	132
11.2.1	Downloading and Installing App	132
11.2.2	Operation on the SolaXCloud App	133
11.3	Operation Guide on SolaXCloud Web	133
12	Troubleshooting and Maintenance	134
12.1	Power Off.....	134
12.2	Troubleshooting.....	134
12.3	Meter/CT Fault	144
12.4	Maintenance.....	145
12.4.1	Maintenance Routines	145
12.4.2	Replacement of Fans.....	146
12.4.3	Upgrading Firmware.....	147
13	Decommissioning.....	150
13.1	Disassembling the Inverter	150
13.2	Packing the Inverter	153
13.3	Disposing of the Inverter	153
14	Technical Data	154
15	Appendix	161
15.1	Installation Video	161
15.2	Application of Generator.....	161
15.2.1	Introduction of Generator Application	161
15.2.2	Notice for Generator Application.....	162
15.2.3	ATS Control Mode.....	163
15.2.4	Dry Contact Mode.....	165
15.3	Application of Adapter Box G2	168
15.3.1	Introduction of Adapter Box G2 Application.....	168
15.3.2	Communication Connection with Inverter.....	169
15.4	Application of EV Charger.....	171
15.4.1	Introduction of EV-Charger Application	171
15.4.2	Wiring Connection Diagram.....	171
15.4.3	Communication Connection with Inverter.....	172
15.4.4	Setting for EV Charger	173

15.5 Application of DataHub	174
15.5.1 Introduction of DataHub Application.....	174
15.5.2 Wiring Connection Diagram.....	174
15.5.3 Communication Connection with Inverter.....	175
15.5.4 Settings for DataHub.....	176
15.6 Micro-grid Application	177
15.6.1 Introduction of Micro-grid Application.....	177
15.6.2 Wiring Connection Diagram.....	177
15.6.3 Working Modes.....	178
15.6.4 Cable Connection (Hybrid Inverter)	180
15.6.5 Cable Connection (On-grid Inverter).....	180
15.6.6 Cable Connection (Meter).....	180
15.7 Application of Parallel Function	182
15.7.1 Introduction of Parallel Application.....	182
15.7.2 Notice for Parallel Application.....	183
15.7.3 System Wiring Procedure.....	185
15.8 Cable Cover.....	190
15.8.1 Appearance.....	190
15.8.2 Scope of Delivery	191
15.8.3 Additionally Required Materials.....	191
15.8.4 Installation Steps.....	191

1 Safety

1.1 General Safety

The series inverter has been meticulously designed and tested to comply with the relevant state and international safety standards. Nevertheless, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the inverter to minimize the risk of personal injury and ensure a safe installation.

Please carefully read, comprehend, and strictly adhere to the comprehensive instructions provided in the user manual and any other relevant regulations prior to the installation of the inverter. The safety instructions in this document serve as supplementary guidelines to local laws and regulations.

SolaX shall not be liable for any consequences resulting from the violation of the storage, transportation, installation, and operation regulations outlined in this document. Such consequences include, but are not limited to:

- Inverter damage caused by force majeure events, such as earthquakes, floods, thunderstorms, lightning, fire hazards, volcanic eruptions, and similar events.
- Inverter damage due to human causes.
- Inverter damage caused by strong vibrations from external factors before, during and after installation.
- Usage or operation of the inverter in violation of local policies or regulations.
- Failure to comply with the operation instructions and safety precautions provided with the product and in this document.
- Improper installation or usage of the inverter in unsuitable environmental or electrical conditions.
- Unauthorized modifications to the product or software.
- Inverter damage occurring during transportation by the customer.
- Storage conditions that do not meet the requirements specified in this document.
- Installation and commissioning performed by unauthorized personnel who lack the necessary licenses or do not comply with state and local jurisdiction regulations.

1.2 Safety Instructions of PV, Inverter and Grid

Save these important safety instructions. Failure to do so may result in damage to the inverter and injury or even loss of life.

1.2.1 Safety Instructions of PV

DANGER!

Potential risk of lethal electrical shock associated with the photovoltaic (PV) system

- Exposure to sunlight can result in the generation of high DC voltage by PV modules, which can lead to electric shock causing severe injuries or even death.
- Never touch the positive or negative poles of the PV connecting device, and avoid touching both poles simultaneously.
- Do not ground the positive or negative poles of the PV modules.
- Only qualified personnel can perform the wiring of the PV modules.

WARNING!

- Overvoltage protection with surge arresters should be provided when the PV power system is installed. The inverter is fitted with SPDs on both PV input side and MAINS side.
- Please consult professionals before installing SPDs.

WARNING!

- Make sure that the input DC voltage does not exceed the maximum DC input voltage specified for the inverter. Overvoltage can cause irreversible damage to the inverter, and such damage is not covered by the warranty.
- PV modules should have an IEC61730 class A rating.

1.2.2 Safety Instructions of Inverter

DANGER!

Potential risk of lethal electrical shock associated with the inverter

- Only operate the inverter if it is in a technically faultless condition. Operating a faulty inverter may lead to electric shock or fire.
- Do not attempt to open the enclosure without authorization from SolaX. Unauthorized opening of the enclosure will void the warranty and can result in lethal danger or serious injury due to electric shock.
- Make sure that the inverter is reliably grounded before any operation to prevent the risk of electric shock causing lethal danger or serious injury.
- Only qualified personnel can perform the installation, wiring, maintenance of the inverter by following this document and the related regulations.

DANGER!

- Prior to any wiring connection, establishing an earth connection is essential.

 WARNING!

- During operation, avoid touching any parts of the inverter other than the DC switch and LCD panel.
- Never connect or disconnect the AC and DC connector while the inverter is running.
- Prior to conducting any maintenance, turn off the AC and DC power and disconnect them from the inverter. Wait for 5 minutes to fully discharge the energy.

 WARNING!**Potential danger of scalding due to the hot enclosure of the inverter**

- Avoid touching the inverter while it is running, as it becomes hot during operation and may cause personal injuries.

 WARNING!

- When handling the battery, carefully follow all safety instructions provided in the battery manual. The battery used with the inverter must meet the specified requirements of the series inverter.

 CAUTION!

- Make sure that children are supervised to prevent them from playing with the device.
- Pay attention to the weight of the inverter and handle it properly to avoid personal injuries.
- Use insulated tools when installing the device, and always wear personal protective equipment during installation and maintenance.

NOTICE!

- If an external Residual Current Device (RCD) is required by local regulations, verify the type of RCD required. It is recommended to use a Type-A RCD with a rating of 300 mA unless a lower value is required by the specific local electric codes. When required by local regulations, the use of an RCD type B is permitted.
- Keep all product labels and the nameplate on the inverter clearly visible and well-maintained.

1.2.3 Safety Instructions of Utility Grid

NOTICE!

- Only connect the inverter to the grid with the permission of the local utility grid company.

2 Product Overview

2.1 System Description

The X3-ULTRA series is the energy storage inverter that supports grid connection of photovoltaic system. It greatly meets the requirements of solar-powered roofs and supports various intelligent solutions such as load management, wireless metering, dual battery terminals, micro-grid, etc., to achieve efficient and economical energy utilization. The X3-ULTRA series can be used with different capacities of SolaX battery.

2.2 Appearance




Figure 2-1 Appearance

Table 2-1 Description of appearance

Item	Description
Nameplate	Nameplate clearly identifies the device type, serial number, specific DC/AC parameters, certification, etc.
LCD panel, indicators and keys	Screen displays the information; indicators indicate the status of inverter. Keys are used to perform the parameter setting.
DC switch	Disconnect the DC input when necessary.
Electrical connection area	Including PV terminals, battery terminals, AC ports, communication ports, etc.

2.3 Supported Power Grid

There are different ways of wiring for different grid systems. TT/TN-S/TN-C-S/IT are shown as below:




Figure 2-2 Supported power grid-TT




Figure 2-3 Supported power grid-TN-S




Figure 2-4 Supported power grid-TN-C-S




Figure 2-5 Supported power grid-IT

2.4 Symbols on the Label and Inverter

Table 2-2 Description of symbols

Symbol	Description
	CE mark. The inverter complies with the requirements of the applicable CE guidelines.
	TUV certified.
	RCM mark. The inverter complies with the requirements of the applicable RCM guidelines.
	Additional grounding point
	Beware of hot surface. Do not touch a running inverter, as the inverter becomes hot during operation!
	Risk of electric shock. High voltage exists after the inverter is powered on!
	Risk of danger. Potential hazards exist after the inverter is powered on!
	Observe enclosed documentation.
	The inverter can not be disposed together with the household waste.
	Do not operate this inverter until it is isolated from battery, mains and on-site PV generation source.
	Danger to life due to high voltage. Residual voltage exists after the inverter is powered off, which needs 5 minutes to fully discharge. Wait 5 min. before attempting any service.

2.5 Working Principle

2.5.1 Circuit Diagram

The inverter is equipped with multi-channel MPPT for DC input to ensure maximum power even under different photovoltaic input conditions. The inverter unit converts DC into AC that meets the requirements of the power grid and feeds it into the power grid. The principle design of inverter is shown in the figure below:




Figure 2-6 Circuit diagram for X3-ULTRA series inverter

NOTICE!

- MPPT 3 is available for X3-ULT-15KP, 20KP, 25K, 25KW, 30K and 15K-GLV inverter.
- X3-ULT-10K-GLV and X3-ULT-15K-GLV without N wire.

2.5.2 Application Schemes

Most countries




Figure 2-7 Whole home backup for most countries




Figure 2-8 Partial home backup for most countries



- The N wire is connected to the PE, and the diameter of the N wire must not be smaller than the diameter of the L wire.

2.6 Working State

The series inverter has Waiting, Checking, Normal, EPS Checking, EPS, Fault, Idle and Standby state.

Table 2-3 Description of working state

State	Description
Waiting	The inverter is waiting for the following two conditions to be met in order to enter the Checking state: • The adequate photovoltaic input voltage. • The AC side voltage and frequency meet the grid requirements specified by the grid regulations.
Checking	• The inverter is checking for conditions to enter Normal state.
Normal	• The inverter is working normally.
EPS Checking	• The inverter is checking for conditions to enter EPS state.
EPS	• The inverter is working in off-grid state.
Fault	• The inverter detects error occurred and prompts error code.
Idle	• The battery SOC reaches the minimum SOC and there is no sufficient PV input voltage, etc.
Unusual Idle	• The battery needs to be charged but PV and grid power are not allowed to charge the battery
Standby	• A standby state when the power of load is extremely low and there is no sufficient PV input voltage, or a state when the battery SOC is more 10% and there is no sufficient PV input voltage. • In this state, it detects PV connection, load power, etc. to determine whether to exit Standby state and enter Normal state.
Force & Charging	• The inverter enters the Fault state, the PV charges the battery and the utility supplies power to the loads.

NOTICE!

- When the inverter is in an Idle state, you can reset the work mode, the Min SOC and the charging periods through the inverter LCD or the SolaX APP to charge the battery to the Min SOC in the charging periods and then awaken the inverter. Please make sure that the actual battery SOC - the modified Min SOC $\geq$ 2% under a specific work mode, so that other modifications are effective. When the current system time is within the new charging periods you reset, the battery begins charging.

2.7 Working Mode

Working modes are available for you to choose in on-grid status, i.e. Self use, Feed-in priority, Backup, Peak shaving, TOU, Manual and Smart Schedule. You can choose the working modes according to your lifestyle and environment.

When the power supply from the electric power company is stopped due to a power outage, it automatically switches to EPS mode and connects to the distribution board for a specific load, thereby providing power to important electrical appliances.

For how to set the working mode, please refer to the section "10.7.1 User Setting".

2.7.1 Self-use Mode (Priority: Loads > Battery > Grid)

The self-use mode is suitable for areas with low feed-in subsidies and high electricity prices. The power of PV will supply the loads first, and the surplus power will charge the battery, then the remaining power will feed into the grid.




Figure 2-13 Self-use mode

NOTICE!

- Set the export control according to the safety code.

Table 2-4 Description of self-use mode

Time period	Inverter working status
Charging period	• Charge the battery firstly until the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.

Time period	Inverter working status
Discharging period	PV is sufficient (PV → load → battery → grid) The power generated from PV prioritizes supplying the load. Any excess power is then directed towards charging the battery, and if there is still surplus electricity, it can be sold to the grid. In the event that the local utility restricts the sale of electricity to the grid, the Export Control can be set to limit the output to the grid. For specific settings, please refer to "Setting Export Control".
	PV is insufficient (PV+battery → load) The battery discharges power to the load, and once its capacity reaches Min SOC, it automatically ceases discharging.

Note:

Charge battery to: The battery SOC charged from grid. 30% by default, the settable range is 10%–100%.

Min SOC: Minimum SOC of the battery under grid connection. 10% by default, the settable range is 10%–100%.

Charge & Discharge Period

You can set two configurable working periods: charging period and discharging period. The interval not in the charging & discharging period belongs to other time periods.

- Charging period (Default period: 00:00–00:00, closed by default)

In the charging period, the inverter will charge the battery first until the battery SOC reaches the specified **Charge battery to** value set in each working mode. You have the option to configure the inverter to either draw power from the grid or not.

- Discharging period (Default period: 00:00–23:59)

In the discharging period, the inverter will allow the battery to discharge and charge power in accordance with the working mode and load conditions.

- Period not set as forced charging or discharging period

In this period, the inverter will allow the battery to charge but can not discharge power.

NOTICE!

- The charging and discharging period is only applicable for self-use mode, feed-in priority and backup mode. The priority of charging period is higher than all working modes.

2.7.2 Feed-in Priority (Priority: Loads > Grid > Battery)

The feed-in priority mode is suitable for areas with high feed-in subsidies. The power generated from PV is directed towards supplying the loads. Any excess power beyond the load requirements will be fed into the grid.




Figure 2-14 Feed-in priority

Time period	Inverter working status
Charging period	Charge the battery firstly until the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.
Discharging period	PV is sufficient (PV → load → grid → battery) - The power generated from PV is directed towards supplying the loads. Any excess power beyond the load requirements will be fed into the grid. PV is insufficient (PV+battery → load) - PV and battery supply power to the load at the same time, and once the battery capacity reaches Min SOC, it automatically ceases discharging.

Note:

Charge battery to: The battery SOC charged from grid. 50% by default, the settable range is 10%–100%.

Min SOC: Minimum SOC of the battery under grid connection. 10% by default, the settable range is 10%–100%.

NOTICE!

- You can set two configurable working periods: charging period and discharging period in feed-in priority mode. Please refer to "Charge & Discharge Period" for details. In this mode, consider whether the battery can be charged during the day. If it cannot be charged, it is recommended to set a forced charging time period during off-peak electricity rates and allow charging from the grid to the battery.

2.7.3 Backup Mode (Priority: Loads > Battery > Grid)

The backup mode is suitable for areas with frequent power outages.

This mode will maintain the battery capacity at relatively high level to ensure that the emergency loads can be used when grid is off. Same working logic with self-use mode.




Figure 2-15 Backup mode

Table 2-5 Description of backup mode

Time period	Inverter working status
Charging period	Charge the battery firstly until the battery SOC reaches the specified Charge battery to value. You can configure the inverter to either draw power from the grid or not.

Time period	Inverter working status
Discharging period	The working logic remains the same as for self-use mode. The difference is: - In the self-use mode when there is no PV input and the battery SOC reaches Min SOC¹ (on-grid min. SOC), the battery will enter a dormant state. At this time, if the grid power is lost, the inverter cannot switch to EPS mode. - In the backup mode, when there is no PV input and the battery reaches Min SOC (on-grid min. SOC), the inverter enters standby. At this time, if the grid power is lost, it will switch to EPS mode until the battery is discharged to the Min SOC² (off-grid min. SOC).

Note:

Min SOC¹ (on-grid min. SOC): Minimum SOC under grid connection. 30% by default, the settable range is 30%–100%.

Min SOC² (off-grid min. SOC): Minimum SOC under off-grid conditions. 10% by default, the settable range is 10%–100%.

NOTICE!

- You can set two configurable working periods: charging period and discharging period in backup mode. Please refer to "Charge & Discharge Period" for details.

NOTICE!

- If there is a foreseeable power outage, it is advisable to switch to backup mode in advance from other modes.

2.7.4 Peak Shaving Mode

Peak shaving mode is set for levelling out peaks in electricity use. The system is intelligently controlled to ensure charging takes place during off-peak hours and discharging occurs during peak hours.




Figure 2-16 Peak shaving mode

Table 2-6 Description of peak shaving mode

Time Period	Inverter working status
Period A	The grid can charge the battery to MaxSOC within the set ChargePowerLimits. In this period, the battery will not discharge power.
Period B & D	Grid consumption power < PeakLimits (PV + grid → load) The PV and grid will power the load. The battery will not charge or discharge power.
Period C	Grid consumption power > PeakLimits (PV + battery + grid → load) - The battery will discharge energy for loads and thus reduce the amount of energy purchased from the grid. (PV → battery → load → grid) - The battery does not discharge power. The PV charges the battery up to the Reserved SOC before supplying power to the loads. Any excess power beyond the load requirements is first supplied to the loads, and then fed into the grid.

Note:

MaxSOC: The energy taken from grid to charge the battery. 50% by default, the settable range is 10%–100%.

ChargePowerLimits: The charging power from grid. 1000 W by default, the settable range is 0-60000 W

PeakLimits: The load consumption from grid side. 0 W by default, the settable range: 0-60000 W.

Reserved SOC: The lower limit of battery SOC required for later peak shaving period. 50% by default, the settable range is 10–100%.

2.7.5 TOU Mode

In the TOU mode, different working modes, i.e. Self-use, Charging, Discharging, Peaking shaving and Battery off can be set for different time periods in accordance with actual needs and environment conditions through SolaXCloud App or Web.

The day can be divided into up to 24 time slots, and the minimum time slot is 15 minutes, independent working mode can be set for each time slot. Please refer to Web Guide or App Guide for details about how to set the TOU mode.

Time Slot	Working Mode
X:XX–X:XX (e.g. 0:00–0:15)	Choose one mode from Self-use/Charging/Discharging/Battery off/Peaking shaving

Note:

Self-use: Same working logic with "Self-use Mode", but it is not limited by the charging and discharging time slots. The priority of PV: Loads > Battery > Grid.

Charging: The power of PV will charge the battery as much as possible to the set SOC of **Charge BAT to** (%). You can set whether to Charge from grid. The default value of **Charge BAT to** (%) is 100%. When the battery reaches the set SOC, the surplus power will perform "Self-use Mode" or supply to the grid (based on the system setup), at this point, Charge from grid is not allowed.

Discharging: If allowed by the battery, the system outputs a specified power from the battery based on the set output percentage, controlling the power at the AC port. You need to set the **RatePower** (%) through Web or App when choosing Discharging mode. When the battery **Discharge to** (%) reaches the set SOC, the inverter performs "Self-use Mode".

Peak shaving: The working logic is that when the power consumption from the grid exceeds the set **PeakLimit** value, the battery is allowed to discharge power. The excess power beyond the limit is provided by the combination of photovoltaic and battery to ensure that the maximum power purchased from the grid does not exceed the set limit. You need to set the **PeakLimit** value through Web or App when choosing Peak shaving mode.

Battery off: The battery neither charges nor discharges. The power of PV will supply to loads or the grid. Only when the battery SOC is lower than the system (TOU) Min SOC, the battery can be charged.

2.7.6 EPS Mode (Priority: Loads > Battery)

During a power failure, the system will provide uninterrupted power supply to the EPS loads using the power from PV and the battery. It is important to ensure that the EPS loads should not exceed the maximum output power of the battery.




Figure 2-17 EPS mode

Table 2-7 Description of EPS mode

Battery SOC	Inverter working status
Battery SOC >Min SOC (in off-grid mode)	PV is sufficient (PV → load → battery) The PV prioritizes supplying power to the load, with any excess energy being directed towards charging the battery.
	PV is insufficient (PV + battery → load) The PV prioritizes supplying power to the load. If the energy is not enough, the battery will discharge power until the battery SOC reaches Min SOC and then error of BatPowerLow will be reported.
Battery SOC ≤Min SOC (in off-grid mode)	The inverter reports BatPowerLow . When there is PV, it will charge the battery first. After charging to the set Min ESC SOC value, it will be automatically recovered and enter EPS mode again.

Note:

Min SOC: Minimum SOC of the battery under off-grid conditions. 10% by default, the settable range: 10%-100%.

Min ESC SOC: The minimum SOC of the battery to enter EPS mode. 30% by default, the settable range: 15%-100%.

NOTICE!

- When the battery supplies power to the load, the available capacity of the battery decreases as the SOC decreases.

2.7.7 Smart Schedule Mode

Smart Schedule mode is based on the fact that the inverter is connected to a DataHub, which makes intelligent predictions and automatically adjusts the inverter's operating mode based on the information it obtains.

In the Smart Schedule mode, different working modes, i.e. Self-use(SS), Feedin priority(SS), BAT Not Discharge(SS) can be set for different time periods in accordance with actual needs and environment conditions through SolaXCloud App or Web.

Note:

Self-use(SS): Same working logic with "Self-use Mode", but it is not limited by the charging and discharging time slots. It is also not allowed to draw power from the grid. The priority of PV: Loads > Battery > Grid.

Feedin priority(SS): Same working logic with "Feedin priority Mode", but it is not limited by the charging and discharging time slots. It is also not allowed to draw power from the grid. The priority of PV: Loads > Grid > Battery .

BAT Not Discharge(SS): The PV will power the load. When PV is insufficient, the grid will power to the load. The battery not discharge power. The priority of PV: Loads > Battery.

2.7.8 Manual Mode

This working mode is only for the professional technical personnel to perform debugging and maintenance. It includes **Forced Discharge**, **Forced Charge** and **Stop chrg&dischrg**. The system will restore to the original working mode after six hours Manual mode set.

2.7.9 Export Control Function

Solar export control is a limit on the amount of energy your solar system that can export into the grid. You have a set limit on how much energy you can export to the grid.

How Export Control works

- CT/Meter required
- Correct setting of the limit value of **Export Control** through inverter. (For parallel system, set on the master inverter)




Figure 2-18 Zero export control with **Phase Unbalance** disabled




Figure 2-19 Zero export control with **Phase Unbalance** enabled

Note:

Export Control value can be set from 0W to more than the rated output power.

For how to set the **Export Control** function, please refer to ["Setting Export Control"](#).

X3-ULT-10K-GLV and X3-ULT-15K-GLV do not support connecting unbalanced loads.

3 System Overview

NOTICE!

- The system diagram indicates the supported connection schemes, but some solutions cannot be used at the same time

System Overview




Figure 3-1 System overview diagram

Table 3-8 System item description

Item	Description
X3-ULTRA series	X3-ULTRA series is an energy storage inverter that supports grid connection of a photovoltaic system.
PV modules	PV modules work in MPPT mode. The maximum number of MPPT is two for 15 kW and 20 kW inverters and three for 25 kW and 30 kW inverters.
Battery	The series inverter should be coupled with lithium-ion battery. Two battery terminals can be connected with two strings of battery. It communicates with the inverter via BMS and must comply with the specifications of the regulations.
Meter/CT	The meter/CT is used by the inverter for import/export or consumption readings, and manages the battery charge/discharge accordingly for smart energy management applications. Wireless meter solution is supported.
Additional on-grid inverter (supported)	The series inverter supports micro-grid function that makes hybrid inverter simulate the grid to active on-grid inverter during off-grid period by connecting on-grid inverter to hybrid inverter's EPS port. Please refer to "15.5 Micro-grid Application" for specific wiring and setting.
Adapter Box G2 (supported)	With SolaX Adapter Box G2, you can connect the smart heat pump to the energy storage systems, realizing the control of the heat pump through inverter. Please refer to "15.2 Application of Adapter Box G2" for specific wiring and setting.
DataHub (supported)	SolaX DataHub is a professional device that for monitoring platforms of photovoltaic power generation systems, which enables data collection, storage, output control, centralized monitoring, and centralized maintenance of devices such as inverters, electricity meters, and environmental monitoring instruments in photovoltaic power generation systems. Please refer to "15.4 Application of DataHub" for specific wiring and setting.
Smart EV Charger (supported)	The series inverter can communicate with SolaX EV Charger to form an intelligent photovoltaic, storage and EV charging energy system, thus maximizing the utilization of photovoltaic energy. Please refer to "15.3 Application of EV Charger" for specific wiring and setting.
Generator (supported)	SolaX PV-Genset solution ensures optimum interaction between the photovoltaic and diesel generator, which saves fuel, lowers energy costs and ensures a stable and reliable power supply. Please refer to "15.1 Generator Application" for specific wiring and setting.
Grid	400 V/230 V and 380 V/220 V grid are supported. (230 V/133 V and 220 V/127 V grid are supported for X3-ULT-10K-GLV and X3-ULT-15K-GLV.)

Item	Description
SolaXCloud	SolaXCloud is an intelligent, multifunctional monitoring platform that can be accessed either remotely or through a hard wired connection. With the SolaXCloud, the operators and installers can always view key and up to date data.

4 Transportation and Storage

If the inverter is not put into use immediately, the transportation and storage requirements needs to be met:

Transportation

- The inverter must be transported in its original packaging. SolaX will not be held responsible for any damage to the inverter caused by improper transportation or by transportation after it has been installed.
- Observe the caution signs on the packaging of inverter before transportation.
- Pay attention to the weight of inverter. Be cautious to avoid injury when carrying X3-ULTRA (gross weight: 54 ± 1.5 kg for X3-ULT-15KP and 20KP; 52.5 ± 1.5 kg for X3-ULT-15K, 19.9K, 20K, 10K-GLV and 15K-GLV; 56 ± 1.5 kg for X3-ULT-25K, 25KW and 30K). Transport according to the personnel quantity required by local regulations.
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the inverter, hold the handle position and the bottom position of the inverter. Keep the inverter horizontal in case of falling down.




Figure 4-1 Caution signs on the packaging

Storage

- The inverter must be stored indoors.
- Do not remove the original packaging material and check the outer packaging material regularly.
- The storage temperature should be between -40°C and $+70^{\circ}\text{C}$. The humidity should be between 5% and 65%.
- Stack the inverter in accordance with the caution signs on the inverter carton to prevent their falling down and device damage. Do not place it upside down.


5 Preparation Before Installation

5.1 Selection of Installation Location

The installation location selected for the inverter is quite critical in the aspect of the guarantee of machine safety, service life and performance. It has the IP66 ingress protection, which allows it to be installed outdoor. The installation position shall be convenient for wiring connection, operation and maintenance.

5.1.1 Environment Requirement

- The ambient temperature: -35°C to $+60^{\circ}\text{C}$;
- The relative humidity shall be between 0–100%RH;
- Do not install the inverter in the areas where the altitude exceeds 3000 m;
- Install the inverter in a well-ventilated environment for heat dissipation; You are recommended to install an awning over it if the inverter is installed on a support outdoor;
- Do not install the inverter in areas with flammable, explosive and corrosive materials or near antenna;
- Avoid direct sunlight, rain exposure and snow laying up.



NOTICE!

- For outdoor installation, precautions against direct sunlight, rain exposure and snow accumulation are recommended.
- Exposure to direct sunlight raises the temperature inside the device. This temperature rise poses no safety risks, but may impact the device performance.
- Install the inverter at least 500 meters away from the coast and avoid sea breeze directly hit.




Figure 5-1 Recommended installation position




Figure 5-2 Incorrect installation position

NOTICE!

- For the installation of the whole system, please refer to the specific environment requirement of each unit.

5.1.2 Installation Carrier Requirement

The installation carrier must be made of a non-flammable material, such as solid brick, concrete, etc. and be capable of supporting the weight of the inverter and suitable of the dimensions of the inverter. If the wall strength is not enough, (such as wooden wall, the wall covered by thick layer of decoration) it must be strengthened additionally.




Figure 5-3 Installation carrier requirement

NOTICE!

- Please take the weight of battery into account when wall-mounting the whole system.

5.1.3 Clearance Requirement

The minimum clearance reserved for the connected terminal and port at the bottom of inverter should be 10 cm. When planning installation space, it is important to simultaneously consider the bending radius of the wires.

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the inverter must meet the standards indicated below.

For installations with multiple inverters, make sure to leave a minimum space of 30 cm between each inverter. In areas with high ambient temperatures, increase the clearances between the inverters and provide adequate fresh air ventilation if feasible.




Figure 5-4 Clearance requirement for single inverter




Figure 5-5 Clearance requirement for multiple inverter

5.2 Tools Requirement


Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site. The following tools must all comply with regulatory requirements.



Hammer drill
(drill bit: Ø12 mm)



Multimeter
(≥ 1100 V DC)




Measuring tape



Utility knife



Marker




Torque screwdriver
(Flat-head bit: M2)
(Phillips head bit: M2.5/M3/M5)
(Hex bit*: H2.5)



Ø2 mm Flat-head
screwdriver




Diagonal pliers




Wire stripper




Crimping tool for RJ45



Crimping tool for
PV terminals




Rubber mallet




Crimping tool




Crimping tool for ferrules




Wire cutter




Torque wrench



Spirit level



Heat gun



Anti-dust mask



Safety gloves



Safety boots



Safety goggles

*For the H2.5 hex bit, the shaft diameter must not exceed 3.5 mm within the first 25 mm from the tip.

5.3 Additionally Required Materials

Table 5-9 Additionally required wires

No.	Required Material	Type	Conductor Cross-section
1	PV wire	 Dedicated PV wire with a voltage rating of 1000 V, a temperature resistance of 105°C, a fire resistance grade of VW-1	4 mm ² –6 mm ²
2	Communication wire 1	 Network cable CAT5E/CAT6	-
3	Communication wire 2	 Four-core signal cable	0.25 mm ² –0.3 mm ²
4	Grid and EPS wire for	 Five-core copper cable	10 mm ² /16 mm ²
Note: For X3-ULT-10K/15K-GLV, prepare 10 mm ² /16 mm ² four-core copper cable.			
5	Additional PE wire	 Conventional yellow and green wire	Consistent with Grid and EPS wire

Table 5-10 Breaker recommended for grid connection (with EPS)

Model	X3-ULT-15KP X3-ULT-15K X3-ULT-10K-GLV	X3-ULT-19.9K X3-ULT-20K X3-ULT-20KP	X3-ULT-25K X3-ULT-30K X3-ULT-25KW X3-ULT-15K-GLV
On-grid Breaker	63 A	63 A	63 A

Table 5-11 Breaker recommended for grid connection (without EPS)

Model	X3-ULT-15KP X3-ULT-15K X3-ULT-10K-GLV	X3-ULT-19.9K X3-ULT-20K X3-ULT-20KP	X3-ULT-25K X3-ULT-30K X3-ULT-25KW X3-ULT-15K-GLV
On-grid Breaker	32 A	40 A	63 A

Table 5-12 Breaker recommended for off-grid connection (only EPS)

Model	X3-ULT-15KP X3-ULT-15K X3-ULT-10K-GLV	X3-ULT-19.9K X3-ULT-20K X3-ULT-20KP	X3-ULT-25K X3-ULT-30K X3-ULT-25KW X3-ULT-15K-GLV
EPS Breaker	32 A	40 A	63 A

6 Unpacking and Inspection

6.1 Unpacking

- The inverter undergoes 100% testing and inspection before shipping from the manufacturing facility. However, transport damage may still occur. Before unpacking the inverter, please check the outer packing materials for damage, such as holes and cracks.
- Unpacking the inverter according to the following figure.




Figure 6-1 Unpacking the inverter

- Be careful when dealing with all package materials which may be reused for storage and relocation of the inverter in the future.
- Upon opening the package, check whether the appearance of the inverter is damaged or lack of accessories. If any damage is found or any parts are missing, contact your dealer immediately.

6.2 Scope of Delivery




Table 6-1 Packing list

Item	Description	Quantity
/	Inverter	1 pcs
/	Bracket	1 pcs
A	Positive PV connector	6 pairs (4 pairs for X3-ULT-15K, 19.9K and 20K and 10K-GLV, 6 pairs for X3-ULT-15KP, 20KP, 25K, 25KW, 30K and 15K-GLV)
B	Positive PV pin contact	
C	Cable fixture	1 pcs

Unpacking and Inspection

Item	Description	Quantity
D	Negative PV connector	6 pairs (4 pairs for X3-ULT-15K, 19.9K and 20K and 10K-GLV, 6 pairs for X3-ULT-15KP, 20KP, 25K, 25KW, 30K and 15K-GLV)
E	Negative PV pin contact	
F	OT terminal	2 pcs (1 pcs for 10 mm ² wire, 1 pcs for 16 mm ² wire)
G	Expansion screw	5 pcs
H	M5 screw	2 pcs
I	Positive & battery connector	2 pcs
J	Negative battery connector	2 pcs
K	RJ45 terminal	8 pcs
L	RJ45 connector	1 pcs
M	8-pin terminal block	1 pcs
N	7-pin terminal block	1 pcs
O	Document	/
P	Handle	2 pcs
Q	Removal tool (Fast removal of terminals)	1 pcs
R	CT	1 pcs
S	AC connector (black)	1 pcs (Supports a minimum wire diameter of 4 mm ² .)
T	Allen key	1 pcs
U	Removal tool for AC connector	1 pcs
V	AC connector (grey)	1 pcs (Supports a minimum wire diameter of 4 mm ²)
W	Allen key	1 pcs
X	Removal tool for AC connector	1 pcs
Y	Positive PV dustproof buckle	6 pairs (4 pairs for X3-ULT-15K, 19.9K and 20K and 10K-GLV, 6 pairs for X3-ULT-15KP, 20KP, 25K, 25KW, 30K and 15K-GLV.)
Z	Negative PV dustproof buckle	
A1	Communication connector	2 pcs

Item	Description	Quantity
A2	63 A manual changeover switch	1 pcs (Only for Australia and New Zealand. Used to switch to the bypass circuit.)
	Dongle (optional)	1 pcs

Note:

- Refer to the actual delivery for the optional accessories. The figures of packing list takes 30 kW inverter as an example.
- The included Allen key (part T & W) is for temporary use only. It is recommended to use a professional hex tool and a torque wrench to achieve the specified torque. Failure to apply correct torque may damage the AC terminals.
- This section uses a specific dongle model as an example. Please refer to your actual dongle. For dongle installation, see its documentation.

7 Mechanical Installation

WARNING!

- Only the qualified personnel can perform the mechanical installation following the local standards and requirements.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.

CAUTION!

- Always be aware of the weight of the inverter. Personal injuries may result if the inverter is lifted improperly or dropped while being transported or mounted.
- Use insulated tools when installing the device. Personal protective equipment must be worn during installation and maintenance.
- Tighten the screws to the torque specified in this document. Otherwise, the inverter might be damaged. This damage is not covered by the warranty.

NOTICE!

- Install the inverter at a maximum back tilt of 5 degrees and avoid forward tilted, side tilted, or upside down.




Figure 7-1 Correct installation




Figure 7-2 Incorrect installation

7.1 Dimensions for Mounting

Check the dimensions of the bracket before mounting and reserve sufficient space for heat dissipation and installation of the whole system.




Figure 7-3 Dimensions 1 (unit: mm)




Figure 7-4 Dimensions 2 (unit: mm)

7.2 Installation Procedures

Step 1: Align the bracket horizontally on the wall and mark the position of the drill holes.




Figure 7-5 Marking the holes

NOTICE!

- Take the height of the stacked battery into account when mounting the bracket.
- Observe the bubble of spirit level and adjust the bracket until the bubble stays in the middle.

Step 2: Set the bracket aside and drill holes with Ø12 drill bit. The depth of the holes should be 90 mm.




Figure 7-6 Drilling holes

Step 3: Knock the expansion screws (part G) into the holes and secure the bracket to the wall with screws by torque wrench.




Figure 7-7 Inserting the screws

Step 4: Open the anti-static bag and take out the inverter and install the handle (part P).




Figure 7-8 Installing the handles

NOTICE!

- Avoid placing the inverter in a way that the wiring terminals are in contact with the floor or any other objects as they are not designed to bear the weight of the inverter.
- If the inverter is temporally needed to be placed on the ground, use foam or other protective materials to prevent any damage of inverter.

- Step 5:** Lift the inverter by the handles and hang it on the bracket. The buckle on the bracket must be hooked into the key ways of the inverter. And then remove the handles.




Figure 7-9 Hanging the inverter

- Step 6:** Secure the inverter to the bracket with M5 screw (part H).




Figure 7-10 Securing the inverter

- Step 7:** (Optional) For safety reason, install an anti-theft lock. Please note that the lock is not in the scope of delivery. Prepare it suitable for the lock hole diameter ($\varnothing < 10 \text{ mm}$) by yourself. Keep the key to the lock in a safe place.




Figure 7-11 Locking the inverter

8 Electrical Connection

⚠ DANGER!

- Before electrical connection, make sure the DC switch and AC breaker are disconnected. Otherwise, electrical shock may be caused by high voltage, resulting in serious personal injury or death.

⚠ WARNING!

- Only the qualified personnel can perform the electrical connection following the local standards and requirements.
- Follow this manual or other related document to wire connection. The device damage caused by incorrect cabling is not in the scope of warranty.
- Use insulated tools and wear individual protective tools when connecting cables.

NOTICE!

- The cable colours in figures shown in this manual are for reference only. Please select cables according to local cable standards.

8.1 Overview of Electrical Connection

8.1.1 Terminals and Ports of Inverter




Figure 8-1 Terminals and ports of inverter

Table 8-2 Description of terminals and ports

Item	Name	Description	Decisive voltage class
A	DC SWITCH	Disconnect the PV input when necessary	-
B	PV 1, PV2, PV3	PV1 and PV2 terminals for X3-ULT-15K, 19.9K 20K and 10K-GLV inverter; PV1, PV2 and PV3 terminals for X3-ULT-15KP, 20KP, 25K, 25KW 30K and 15K-GLV inverter	DVC-C
C	COM 1	Communication port for Parallel-1, Parallel-2, BMS-1, BMS-2, RS485, DRM	DVC-A
D	COM 2	Communication port for Ripple control, DIO, Meter/CT	DVC-A
E	DONGLE	Firmware upgrading and dongle connection	DVC-A
F	GRID	AC port connecting to power grid	DVC-C
G	-	Fans	-
H		Additional grounding point	-
I	BAT 1, BAT 2	Battery terminal connecting battery power cable	DVC-C
J	EPS	AC port connecting to EPS load	DVC-C

8.1.2 Cable Connections of Inverter




Figure 8-2 Cable connections of inverter

Table 8-3 Descriptions of connected part

Item	Part	Description	Source
A	PV module	A PV string is composed of the PV modules connected in series. The number of input PV strings varies in accordance with different models.	Prepared by user
B	(Optional) X3-ULTRA series inverter	Select a same model of inverter	Purchased from SolaX
C	(Optional) SolaX communication device	SolaX DataHub, Adapter Box G2 and EV-Charger are supported. Select the device as needed.	Purchased from SolaX
D	Power grid scheduling device (only applicable to Australia and New Zealand)	Select the devices that meet the power grid scheduling requirements.	Prepared by user
E	Meter/CT	Supported meter: SolaX authorized DTSU666, DTSU666-CT, Wi-BR, M3-40 and M3-40-Dual	Purchased from SolaX
F	(Optional) Ripple control receiver	Select the devices that meet the power grid management requirements.	Prepared by user

Item	Part	Description	Source
G	(Optional) Dry contact controlled device	Generator and system switch are supported. For generator, select a generator equipped with an Automatic Transfer Switch (ATS), and the rated output power of the generator should be greater than the sum of the load power and the battery charging power. For system switch, select a self-locking switch.	Prepared by user
H	AC switch	Select an appropriate AC switch according to the local regulations to ensure the inverter can be securely disconnected from the grid when an emergency occurs. Refer to "5.3 Additionally Required Materials" for the recommended specifications of AC switch.	Prepared by user
I	Battery	T-BAT-SYS-HV-S2.5/3.6, T-BAT-SYS-HV-5.8, T-BAT-SYS-HV-3.0 and TSYS-HS51 can be connected with the series inverter.	Purchased from SolaX
J	(Optional) Monitoring dongle	Only SolaX monitoring dongle supported.	Purchased from SolaX

Table 8-4 Descriptions of cables

Item	Cable	Type and specifications	Source
1	PV DC input power cable	Refer to "5.3 Additionally Required Materials".	Prepared by user
2	RS485 communication cable		Prepared by user
3	RS485 communication cable		Prepared by user
4	RS485 communication cable		Prepared by user
5	RS485 communication cable		Prepared by user
6	Signal cable		Prepared by user
7	AC output cable		Prepared by user
8	Battery power cable		Delivered with battery

9	Battery communication cable	Refer to "5.3 Additionally Required Materials".	Prepared by user
10	PE cable		Prepared by user
11	Signal cable		Prepared by user

8.2 PE Connection

The inverter must be grounded reliably. The connection point has been labelled with the following label: . We recommend that the inverter is earthed to a nearby grounding point.

NOTICE!

- X3-ULTRA series inverter has the grounding detection function which is used to check whether the inverter is properly grounded before it starts. If the inverter is not connected with earth, the inverter will turn on a red light and report **Earth Fault**.

PE connection procedures

Step 1: Strip the insulation of conductor by wire stripper.

- Stripping length of 16 mm² wire is 13.5 mm–15.5 mm;
- Stripping length of 10 mm² wire is 12.5 mm–14.5 mm.




Figure 8-3 Stripping the PE cable

Step 2: Insert the stripped section into the OT terminal (part F).




Figure 8-4 Installing the tubing and OT terminal

Step 3: Crimp it with crimping tool.




Figure 8-5 Crimping the cable

Step 4: Loosen the PE screw on the inverter with cross screwdriver.




Figure 8-6 Disassembling the screw

Step 5: Connect the PE cable to the inverter and secure it with the original screw (Torque: $2.0 \pm 0.2 \text{ N}\cdot\text{m}$).




Figure 8-7 Securing the PE cable

8.3 AC Connection

NOTICE!

- Before connecting the inverter to the grid, approval must be received by local utility as required by national and state interconnection regulations.

The inverter has an EPS function. When the grid is connected, the inverter outputs go through the on Grid port, and when the grid is disconnected, the inverter outputs go through the EPS port.

Requirements for AC connection

- Grid Voltage requirement
 - » The grid voltage and frequency must be within the allowable range (230 V/133 V, 220 V/127 V, 50/60 Hz for X3-ULT-10K/15K-GLV and 400 V/230 V, 380 V/220V, 50/60 Hz for other models) and comply with the requirements of the local power grid.
- Residual Current Device (RCD)
 - » The inverter does not require an external RCD when operating. If an external RCD is required by local regulations, a 300 mA Type-A RCD is recommended. If required by local regulations, a Type-B RCD is also permitted.
- AC breaker
 - » An AC breaker that matches the power of the inverter must be used between the inverter output and the power grid. Each inverter must be equipped with an independent breaker or other load disconnection unit to ensure the safe disconnection from the grid. For specific information on the AC breaker for Grid and EPS, see "5.3 Additionally Required Materials".
- EPS load
 - » Make sure that the rated power of the EPS load is within the rated output power range of the inverter. Otherwise, the inverter will report an **EPS Overload Fault** alarm. In this case, turn off some loads to suit the rated EPS output power range of the inverter, and then press the ESC key on the LCD screen to clear the fault.
 - » When connecting to the EPS port, pay attention to the following points:

Medical equipment	Connection prohibited
Precision instrument	Connection prohibited
Appliances susceptible to malfunctions in the event of power outages during use.	Connection prohibited

- » For inductive loads such as refrigerators, air conditioner, washing machine, etc., ensure that their start power does not exceed the EPS peak power of the inverter.

Table 8-5 EPS load information

Type of load	Equipment	Start power
Resistive load	Lamp	Rated power
	Fan	Rated power
	Hair dryer	Rated power
	Refrigerator	3–5 times rated power
Inductive load	Air conditioner	3–6 times rated power
	Washing machine	3–5 times rated power
	Microwave oven	3–5 times rated power

* Refer to the start power of the equipment for the actual start power.

Wiring procedures

NOTICE!

- This section takes the wiring of the Grid port for example. It is also applicable to the wiring of the EPS port.
- **The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire.**

Step 1: Prepare a five-core cable as the Grid cable and strip the insulation of L1, L2, L3, N and the grounding conductor to an appropriate length.




Figure 8-8 Stripping the Grid cable

Step 2: Disassemble the AC connector (part S for Grid port, part V for EPS port) as below. Remove rubber plugs based on the actual wire diameter.




Figure 8-9 Disassembling the AC connector

Step 3: Thread the Grid cable through swivel nut and connector enclosure in sequence.




Figure 8-10 Threading the Grid cable

Step 4: Insert the conductors L1, L2, L3, N, and grounding conductor into the ferrules. Use crimping tool for ferrules to crimp it. Make sure the conductors are correctly assigned and firmly seated in the ferrules.




Figure 8-11 Stripping the end of cable and crimping it

- Step 5:** Insert the crimped conductors L1, L2, L3, N, and grounding conductor into the terminal block according to the labeling and tighten the terminal block screws with the torque screwdriver.




Figure 8-12 Assembling the AC connector

NOTICE!

- It is recommended to use an H2.5 hex driver bit with a screwdriver to achieve the specified torque. Ensure that the bit's shaft diameter does not exceed 3.5 mm within the first 25 mm from the tip.

- Step 6:** Remove the AC caps and plug the assembled AC connectors into Grid port and EPS port correspondingly.




Figure 8-13 Installing the AC connector to inverter




Figure 8-14 The EPS port is not connected

 DANGER!

- Before powering on the inverter, make sure the AC connectors are properly installed correctly on the Grid and EPS port even if the EPS port is not wired. Otherwise, electrical shock may be caused by high voltage, resulting in serious personal injury or death.

 WARNING!

- Reinstall AC caps immediately after removing the connectors from ports.

8.4 PV Connection

 DANGER!

- When exposed to the sunlight, PV modules will generate lethal high voltage. Please take precautions.
- Before connecting the PV modules, make sure that both DC switch and AC breaker are disconnected, and that the PV module output is securely isolated from the ground.

 WARNING!

- To mitigate the risk of fire, it is crucial to utilize a dedicated crimping tool specifically designed for PV installations to ensure secure and reliable connections.

 CAUTION!

- Power is fed from more than one source and more than one live circuit.

Requirements for PV connection

- Open-circuit voltage and operating voltage
 - » The open circuit voltage of each module array cannot exceed the maximum PV input voltage (600 V for X3-ULT-10K/15K-GLV; 1000 V for other models) of the inverter. Otherwise, the inverter may be damaged.
 - » The operating voltage of PV modules must be within the MPPT voltage range (160–560 V for X3-ULT-10K/15K-GLV; 160–950 V for other models) of the inverter. Otherwise, the inverter will prompt a **PV Volt Fault** alarm. Consider the impact of low temperature on the voltage of the photovoltaic panels, as lower temperatures tend to result in higher voltages.

- PV module
 - » The PV modules within the same MPPT channel are of the same brand. Additionally, the strings within the same channel should have identical quantities, and be aligned and tilted identically.
 - » The positive or negative pole of the PV modules is not grounded.
 - » The positive cables of the PV modules must be connected with positive DC connectors.
 - » The negative cables of the PV modules must be connected with negative DC connectors.

Wiring procedures

Step 1: Strip approx. 7 mm of the cable insulation.




Figure 8-15 Stripping the PV cable

Step 2: Insert the stripped cable into the PV pin contact (part B and part E).




Figure 8-16 Inserting the PV pin contact

Step 3: Make sure the PV cable and PV pin contact are of the same polarity. Crimp it with crimping tool for PV terminal. Pay attention to the crimping position.




Figure 8-17 Crimping the terminal

Step 4: Thread the PV cable through swivel nut and insert the cable into the PV connector (part A and part D). until a "Click" is heard. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut clockwise. Verify that the PV connectors have the correct polarity before connection.




Figure 8-18 Threading the PV cable

Step 5: A "Click" will be heard if it is connected correctly. Gently pull the cable backward to ensure firm connection. Tighten the swivel nut clockwise. Verify that the PV connectors have the correct polarity before connection.




Figure 8-19 Securing the PV cable

- Step 6:** Use a voltage measuring device which complies with the local regulation to measure the positive and negative voltage of the assembled PV connectors. Make sure the open circuit voltage does not exceed the input limit.




Figure 8-20 Measuring the voltage of PV connectors

NOTICE!

- If the voltage reading is negative, it indicates an incorrect DC input polarity. Please check if the wiring connections on the multimeter is correct or PV connectors are not mistakenly connected.

- Step 7:** Remove the PV terminals caps and connect the assembled PV connectors to corresponding terminals until there is an audible "Click". The PV+ on the string side must be connected to the PV+ on the inverter side, and the PV– on the string side must be connected to the PV– on the inverter side.




Figure 8-21 Connecting the PV cable

Step 8: (Optional) Fit the unused PV terminals with dustproof buckles (part Y and part Z).




Figure 8-22 Connecting the dustproof buckles

8.5 Battery Power Cable Connection



- Before connecting the cables, make sure the breaker, power button (if any) and DC switch (if any) of battery is OFF.
- Always ensure correct polarity. Never reverse the polarity of the battery cables as this will result in inverter damage.

NOTICE!

- The power cable of battery is in the battery accessory pack. NOT in the scope of inverter's delivery.
- **Must select a battery model that meets the requirements of national and state regulations. You can confirm the certification information of the battery by contacting SolaX.**

Requirements for battery connection

- Battery
 - » SolaX Lithium-ion battery
 - » The inverter is equipped with two independent battery terminals, allowing for connection to two separate battery towers. Max charge and discharge current is 30 A for each BAT terminal.
 - » Make sure the input voltage of each BAT terminal is higher than minimum voltage 120 V and lower than maximum input voltage 800 V.
 Note 1: When the voltage is below 180 V, the inverter will limit the battery current to less than 20 A.
 Note 2: If the total voltage of the connected batteries is less than 127 V and there is no PV input, the system will not able to start.
- Micro circuit breaker (MCB)
 - » If the battery is integrated with a readily accessible internal DC breaker, no additional DC breaker is required. If local regulations mandate the use of a DC MCB between the battery and the inverter, install a non-polar DC MCB.
 - » Nominal voltage of DC breaker should be larger than maximum voltage of battery.
 - » See the documentation of battery for the current. For T-BAT-SYS-HV-S2.5/3.6, T-BAT-SYS-HV-5.8, T-BAT-SYS-HV-3.0 and TSYS-HS51, the current should be 40 A.

- Battery configuration information
 - » For T-BAT-SYS-HV-S2.5, single BAT terminal supports 3-13 packs, 3-26 packs in total.
 - » For T-BAT-SYS-HV-S3.6, single BAT terminal supports 3-13 packs, 3-26 packs in total.
 - » For TSYS-HS51, single BAT terminal supports 3-13 packs, 3-26 packs in total.
 - » For T-BAT-SYS-HV-5.8, single BAT terminal supports 2-4 packs, 2-8 packs in total.
 - » For T-BAT-SYS-HV-3.0, single BAT terminal supports 2-4 packs, 2-8 packs in total.
 - » By connecting a battery parallel box to the inverter, the battery capacity can be increased, SolaX BMS Parallel Box-II G2 supports T-BAT-SYS-HV-5.8 and T-BAT-SYS-HV-3.0 batteries, and the TcBox-70 supports T-BAT-SYS-HV-S2.5/3.6 and TSYS-HS51 batteries. For specific box requirements for the batteries, refer to the User Manual of the box.
- Battery connection scheme (take T-BAT-SYS-HV-S2.5 as an example)
 - » Scheme 1: Connect one battery string to one BAT terminal (BAT 1 or BAT 2). (suitable for the connected battery packs less than 13.)




Figure 8-23 Battery connection Scheme 1




Figure 8-24 Detailed connection for scheme 1

Scheme 2: Connect the two battery strings to BAT 1 and BAT 2 terminal respectively. (Suitable for the connected battery packs more than 13.) Additional BMS is needed.




Figure 8-25 Battery connection scheme 2




Figure 8-26 Detailed connection for scheme 2

NOTICE!

- For scheme 1 and scheme 2: It allows for the full utilization of the battery's capacity based on the different types of batteries. Each BAT terminal of the inverter can operate at a maximum rated current of 30 A. The total voltage of each battery string must meet the voltage requirements of the inverter ranging from 120 V to 800 V. (120 V to 550 V for X3-ULT-10K/15K-GLV)
- » Scheme 3: Connect the battery packs to BAT 1 and BAT 2 terminal simultaneously. Note that the number of battery modules is 13 in maximum for this scheme. Additional ramp-up battery power cable is needed.




Figure 8-27 Battery connection Scheme 3




Figure 8-28 Detailed connection for scheme 3

NOTICE!

- For scheme 3, use an ramp-up battery power cable to connect one battery string to two BAT terminals. It can fully unleash the performance of high-current batteries if the charging and discharging current of the battery exceeds 30 A.
- Install ramp-up battery power cable on the main circuit. For T-BAT-SYS-HV-S2.5/3.6, the current should be 50 A. For TSYS-HS51, the current should be 60 A.

NOTICE!

- Considering factors such as cost, maximizing battery performance, and meeting the voltage requirements of the inverter, please choose a suitable battery connection scheme.
- It is possible to expand the capacity by adding batteries of the same model, Different models of batteries are not supported for expansion.

Wiring procedures



WARNING!

- Do not remove the terminal caps of unused terminals. Reinstall the caps after removing the connectors from the terminals.

Step 1: Strip approx. 15 mm of the cable insulation.




Figure 8-29 Stripping the battery cable

Step 2: Open the spring. Insert the stripped wire with twisted litz wires all the way into the battery connector (part I and part J).




Figure 8-30 Opening the spring

Step 3: The litz wire ends have to be visible in the spring.




Figure 8-31 Threading the battery cable

Step 4: Close the spring until a "Click" is heard. Make sure that the spring is snapped in.




Figure 8-32 Press down on the Spring

Step 5: Push the insert into the sleeve. Tighten the cable gland to 2.0 ± 0.1 Nm.




Figure 8-33 Tighten the cable gland

Step 6: Remove the battery terminal caps and connect the assembled battery connectors to corresponding terminals until there is an audible "Click".





Figure 8-34 Connecting the battery connector

8.6 COM 1 Communication Connection

8.6.1 Pin Assignment of COM 1 Port

The COM 1 port is used for parallel connection via Parallel-1 and Parallel-2 communication port, battery communication via BMS-1 and BMS-2 port, Communicate via RS485 and DRM, or external communication.



Parallel-1 1: Parallel_485A 2: Parallel_485B 3: EPSBOX_RELAY_VCC 4: Parallel_CANH 5: Parallel_CANL 6: GND_COM 7: Parallel_SYNC1 8: Parallel_SYNC2		Parallel-2 1: Parallel_485A 2: Parallel_485B 3: EPSBOX_RELAY_VCC 4: Parallel_CANH 5: Parallel_CANL 6: GND_COM 7: Parallel_SYNC1 8: Parallel_SYNC2	
BMS-1 1: BAT_TEMP 2: GND_COM 3: GND_COM 4: BMS1_CANH 5: BMS1_CANL 6: GND_COM 7: BMS1_485A 8: BMS1_485B		BMS-2 1: BAT_TEMP 2: GND_COM 3: GND_COM 4: BMS2_CANH 5: BMS2_CANL 6: GND_COM 7: BMS2_485A 8: BMS2_485B	
RS485 1: REMOTE_485A 2: REMOTE_485B 3: PARALLEL_485AA 4: PARALLEL_485BB 5: PARALLEL_485BB 6: PARALLEL_485BB 7: REMOTE_485A 8: REMOTE_485B		DRM 1: DRM1/5 2: DRM2/6 3: DRM3/7 4: DRM4/8 5: +3.3V_COM 6: COM/DRM0 7: GND_COM 8: GND_COM	

8.6.2 Parallel Communication Connection

The inverter provides the parallel connection function. One inverter will be set as the **Master** inverter to control the other **Slave** inverters in the system. For details, please refer to "15.6 Application of Parallel Function".

NOTICE!

- The communication cable length between two parallel inverters should not exceed 3 meters, and the total cable length of all parallel inverters should not exceed 30 meters.

Parallel connection wiring procedure

Step 1: Hold the latches on both sides of COM 1 cap to pull it out from the enclosure.




Figure 8-35 Removing the connector enclosure

Step 2: Take out the communication connector (part A1) from the accessory bag. Anti-clockwise loosen the swivel nut and pull out the sealing plugs. Keep them still in the cable support sleeve if you choose not to connect the cable.




Figure 8-36 Disassembling the connector

Step 3: Thread the cable through the swivel nut, cable support sleeve, and connector enclosure in sequence.




Figure 8-37 Threading the cables

Step 4: Install the network cables to Parallel-1 and Parallel-2 of cable fixture (part C) according to the labeling.




Figure 8-38 Installing RJ45 terminal to the cable fixture

Step 5: Connect the connector to COM 1 port. Ensure the cable fixture tongue is well inserted into the slot. You will hear an audible "Click".




Figure 8-39 Inserting the connector to COM 1

Step 6: Secure the assembled connector on COM 1 port.

- a. Install the connector enclosure back into the COM 1 port.
- b. Install the cable support sleeve into the enclosure.
- c. Tighten M3 screw to secure it. (Torque: $0.4 \pm 0.1 \text{ N}\cdot\text{m}$)
- d. Clockwise tighten the swivel nut to finish the COM 1 wiring connection.




Figure 8-40 Securing the connector

8.6.3 BMS Communication Connection

Through BMS-1 and BMS-2 communication port, the inverter can be connected to two independent batteries of different capacities. The model of each battery string must be the same.

BMS connection diagram




Figure 8-41 BMS connection diagram

BMS wiring procedure

- Step 1:** Hold the latches on both sides of COM 1 cap to pull it out from the enclosure..
- Step 2:** Anti-clockwise loosen the swivel nut and pull out the sealing plugs. Keep them still in the cable support sleeve if you choose not to connect the cable.
- Step 3:** Thread the cable through the swivel nut, cable support sleeve, and connector enclosure in sequence.
- Step 4:** Install the network cables to BMS-1 and BMS-2 of cable fixture (part C) according to the labeling.




Figure 8-42 Installing RJ45 terminal to the cable fixture

- Step 5:** Connect the assembled connector to COM 1 port. Make sure the cable fixture part is well inserted into the slot. You will hear an audible "Click" if it is connected securely. Lightly pull the cable backward for double check its connection.
- Step 6:** Secure the assembled connector on COM 1 port.

8.6.4 RS485 Communication Connection

For SolaX products, such as the Adapter Box G2, EV-Charger, and DataHub, they can be connected to pin 3 and pin 6 or pin 4 and pin 5. As for pin 1, pin 2, pin 7, and pin 8, they can be utilized to connect devices other than SolaX products. If you require simultaneous connections of multiple devices, a splitter adapter can be employed.

NOTICE!

- Please refer to "[15 Appendix](#)" for the specific application of Adapter Box G2, EV-Charger and DataHub.
- The cable length of RS485 communication should not exceed 30 meters.
- Not all devices are compatible with 8 pin network cables. In cases where 8 pin network cables are not supported, it is required to re-crimp the RJ45 terminal according to the pin assignment.

External equipment wiring procedure

Step 1: Hold the latches on both sides of COM 1 cap to pull it out from the enclosure.

Step 2: Anti-clockwise loosen the swivel nut and pull out the sealing plugs. Keep them still in the cable support sleeve if you choose not to connect the cable.




Figure 8-43 Disassembling the connector

Step 3: Thread the cable through the swivel nut, cable support sleeve, and connector enclosure in sequence. The communication cable requires cutting off the existing connector and re-crimping the RJ45 terminal(part K).




Figure 8-44 Threading the cables

Step 4: Install the network cable to RS485 of cable fixture (part C) according to the labeling.




Figure 8-45 Installing RJ45 terminal to the cable fixture

Step 5: Connect the assembled connector to COM 1 port. Make sure the cable fixture tongue is well inserted into the slot. You will hear an audible "Click" if it is connected securely. Lightly pull the cable backward for double check its connection.

Step 6: Secure the assembled connector on COM 1 port.

8.6.5 DRM Connection (Applicable to AS/NZS 4777)

According to AS/NZS 4777.2, the inverter needs to support the function of demand response mode (DRM). With the use of an external control box, active or reactive power regulation can be realized in a timely and fast manner, and the inverter can be operated stably during the process of regulation.

DRM 0, DRM 1 and DRM 5 are available now.




Figure 8-46 DRED wiring diagram

Table 8-6 Descriptions of DRM

Mode	Pin location	Requirement
DRM 0	Pin 6	• When S0 is turned on, the inverters shut down. • When S0 is turned off, the inverters restore grid connection..
DRM 1	Pin 1	• When S1 is turned on, the inverters do not input active power.
DRM 5	Pin 1	• When S5 is turned on, the inverters do not output active power.

DRM connection wiring procedure

- Step 1:** Hold the latches on both sides of COM 1 cap to pull it out from the enclosure.
- Step 2:** Anti-clockwise loosen the swivel nut and pull out the sealing plugs. Keep them still in the cable support sleeve if you choose not to connect the cable.
- Step 3:** Thread the cable through the swivel nut, cable support sleeve, and connector enclosure in sequence.
- Step 4:** Install the network cable to RS485 of cable fixture (part C) according to the labeling.




Figure 8-47 Installing RJ45 terminal to the cable fixture

- Step 5:** Connect the assembled connector to COM 1 port. Make sure the cable fixture tongue is well inserted into the slot. You will hear an audible "Click" if it is connected securely. Lightly pull the cable backward for double check its connection.
- Step 6:** Secure the assembled connector on COM 1 port.

8.7 COM 2 Communication Connection

8.7.1 Pin Assignment of COM 2 Port

The COM 2 port is used for Meter/CT connection, ripple control and DIO function.




Table 8-7 Pin assignment of COM 2 port

Pin	Pin assignment
Meter/CT	
1	CT_R1_CON
2	CT_S1_CON
3	CT_T1_CON
4	METER_485A
5	METER_485B
6	CT_T2_CON
7	CT_S2_CON
8	CT_R2_CON
Ripple control	
1	RP_K4
2	GND_COM
3	RP_K3
4	GND_COM
5	RP_K2
6	GND_COM
7	RP_K1
8	GND_COM

Pin	Pin assignment
DIO port	
1	DO_1
2	DO_2
3	DI_1+
4	DI_1-
5	DI_2+
6	DI_2-
7	GND_COM

8.7.2 Meter/CT Connection

The inverter should work with an electric meter or current transformer (CT for short) to monitor household electricity usage. The electricity meter or CT can transmit the relevant electricity data to the inverter or platform.

CAUTION!

- The inverter will shut down and prompt **Meter Fault** alarm if meter is not connected to inverter. Smart meters must be authorized by our company. Unauthorized meter and CT may be incompatible with the inverter, resulting in damage to the inverter and working mode malfunction. SolaX will not be responsible for the impact caused by the use of other appliances.

NOTICE!

- Do not place the CT on the N wire or ground wire.
- Do not put CT on the N wire and L wire at the same time.
- Do not place the CT on the side where the arrow points to the inverter.
- Do not place the CT on non-insulated wires.
- The cable length between CT and inverter should not exceed 100 meters.
- It is recommended to wrap the CT clip around in circles with insulating tape.

Meter/CT Connection Diagram

NOTICE!

- The following figures take inverter with SolaX Meter DTSU666, Wi-BR and CT as examples.
- If you have other power generation equipment (such as an inverter) at home and wants to monitor both equipment, our inverter provides Meter 2 communication function to monitor the power generation equipment. For more information, please contact us.
- Please make PE connection for Meter if the meter has ground terminal.
- **The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire.**

- Meter connection diagram




Figure 8-48 Meter connection diagram 1




Figure 8-49 Meter connection diagram 2

- Wireless Meter connection diagram




Figure 8-50 Wireless Meter connection diagram

- CT connection diagram




Figure 8-51 CT connection diagram

NOTICE!

- The arrow on the CT must point at the public grid.
- CT-R must be connected to L1, CT-S connected to L2, and CT-T connected to L3 in accordance with the L1, L2 and L3 of the inverter's Grid port.

Meter/CT pin definition

	Pin	Pin assignment
For CT connection	1	CT_R1_CON
	2	CT_S1_CON
	3	CT_T1_CON
For Meter connection	4	METER_485A
	5	METER_485B
For CT connection	6	CT_T2_CON
	7	CT_S2_CON
	8	CT_R2_CON

Meter/CT wiring procedure

Step 1: Hold the latches on both sides of COM 2 cap to pull it out from the enclosure.




Figure 8-52 Disassembling the COM 2 port

Step 2: Take out another communication connector (part A1) from the accessory bag. Loosen the swivel nut on the enclosure, and then remove the sealing plugs from the cable support sleeve as needed. Do not remove the sealing plugs from holes if you choose not to connect the cable.




Figure 8-53 Disassembling the connector

Step 3: Thread the cable through the swivel nut, cable support sleeve, and connector enclosure in sequence.




Figure 8-54 Threading the cables

Step 4: Connect the assembled communication cable into the COM 2 port. Secure the assembled connector on COM 2 port.




Figure 8-55 Connecting to COM 2

Step 5: For wire meter connection, insert another side of the communication cable into meter. For CT connection, connect the other side to CT (part R).




Figure 8-56 Connecting to wire meter




Figure 8-57 Connecting to CT

8.7.3 Ripple Control Communication Connection

Ripple Control is a common form of grid management. Its communication is based on superimposing a very high frequency signal onto the 50/60 Hz mains power. The inverter supports to connect a digital signal source (e.g. ripple control receiver) to the digital input.

Requirments for ripple control

- The signal source must be technically suitable for connection to the digital inputs. (see technical data)
- The connected digital signal source has a safe separation to the grid potential.

Connection diagram for ripple control




Figure 8-58 Connection diagram for ripple control

NOTICE!

- When operating in parallel, to make ripple control effective for the system, it is only necessary to set it on the Master.
- If the master fails during parallel operation, the ripple control link remains connected when the slave is configured as the master.




Figure 8-59 Connection diagram for ripple control in parallel

Ripple control wiring procedure

- Step 1:** Hold the latches on both sides of COM 2 cap to pull it out from the enclosure.
- Step 2:** Loosen the swivel nut on the enclosure, and then remove the sealing plugs from the cable support sleeve as needed. Do not remove the sealing plugs from holes if you choose not to connect the cable.




Figure 8-60 Disassembling the connector

- Step 3:** Strip approx.6 mm of the cable insulation. Insert the conductors into the 8-pin terminal block (part M) and tighten the terminal screws (torque: 1.5 N·m). Ensure that the conductors are firmly seated in the terminal.




Figure 8-61 Connecting to 8-pin terminal block

- Step 4:** Connect the assembled communication cable into the COM 2 port. Lightly pull the cable backward to confirm tight insertion and then install the connector back.




Figure 8-62 Connecting to the inverter

8.7.4 DIO Communication Connection

DIO port is designed to communicate with generator and system switch through dry contact.

To enhance safety and reduce the risk of injury, you can install the system switch in a readily accessible location through dry contact connection. In the event of an emergency, the system switch can be easily reached and pressed to promptly switch off the entire system, ensuring a swift response and preventing further harm.

For generator, please refer to "15.1 Generator Application" for specific application.

DIO pin definition

Application	Pin	Pin assignment
For generator dry contact output	1	DO_1
	2	DO_2
For system switch dry contact input	3	DI_1+
	4	DI_1-
Reserved	5	DI_2+
	6	DI_2-
Reserved	7	GND_COM

NOTICE!

- If there is strong interference in the surroundings, it is recommended to use shielding cables and ground the shielding layer of the cables through Pin 7.

System switch connection diagram




Figure 8-63 System switch connection diagram

When system switch is pressed, **OFF MODE (DIO SW)** will be displayed on the LCD screen and the system will be powered off. To release the switch, press it again.

DIO wiring procedure

- Step 1:** Hold the latches on both sides of COM 2 cap to pull it out from the enclosure.
- Step 2:** Loosen the swivel nut and pull out the sealing plugs. Keep them still in the cable support sleeve if you choose not to connect the cable.
- Step 3:** Prepare two four-core signal cable. Trim the excess one core wire. The cut core wire should be insulated. Thread the cables through the swivel nut, cable support sleeve, and connector enclosure in sequence.
- Step 4:** Strip approx.6 mm of the cable insulation. Insert the conductors into the 7-pin terminal block (part N) and tighten the terminal screws (torque: 1.5 N·m.). Ensure that the conductors are firmly seated in the port.




Figure 8-64 Connecting to 7-pin terminal block

- Step 5:** Connect the assembled communication cable into the COM 2 port. Lightly pull the cable to confirm tight insertion and then install the connector back.




Figure 8-65 Connecting to the inverter


9 System Commissioning

9.1 Checking before Power-on

No.	Item	Checking details
1	Installation	The inverter is installed correctly and securely. The battery is installed correctly and securely. Other device (if any) is installed correctly and securely.
2	Wiring	All DC, AC cables and communication cables are connected correctly and securely; The meter/CT is connected correctly and securely. The ground cable is connected correctly and securely;
3	Breaker	All the DC breakers and AC breakers are disconnected;
4	Connector	The external AC and DC connectors are connected; The connectors on the Grid and EPS port are connected correctly and securely.
5	Unused terminal and port	Unused terminals and ports are locked by waterproof caps.
6	Screw	All the screws are tightened.

9.2 Powering on the System


Step 1: Turn on the DC switch and check the LCD screen.



- » If the LCD screen is not on, turn off the DC switch and check whether the PV polarity is connected correctly.
- » If the error of any channel of PV is displayed on LCD, turn off the DC switch and check the corresponding channel of PV connection.

Step 2: Switch on the AC breaker and wait for the inverter power on.

- » During initial power-up, if Meter/CT is connected, automatic check will be enabled:



- » Awaiting the display of the check results. Please refer to "12.3 Meter/CT Fault" for the error code.



Step 3: Switch on the battery or the breaker, button, DC switch of the battery (see documentation of the battery manufacturer).

Step 4: Check the LCD screen and perform **Forced Discharge** and **Forced Charge** through the setting path **Menu>Mode Select >Manual** to verify if the charging and discharging of battery is normal.


9.3 Operation of lockable DC Switch

This series of inverters are provided with two kinds of DC switches: unlockable DC switch (optional; without lock) and lockable DC switch (standard; with lock).





WARNING!

- For Australia, the lockable DC switch is required.
- For lockable DC switch
The lockable DC switch includes 3 states: ON, OFF, and OFF+Lock. The DC switch is in the OFF state by default.





- Turn on the DC switch
Turn on the DC switch from OFF state to ON state.

Turn on DC switch (Australian version)





- Turn off the DC switch
Rotate the DC switch from ON state to OFF state.


Turn off DC switch (Australian version)



- Lock the DC switch
 - Rotate the DC switch to OFF state, then rotate the DC switch to the left side;
 - Push the position indicated by the arrow upward (as shown in the diagram below).
 - (Optional) After pushing the position upward, choose to lock the DC switch with a lock.



- Unlock the DC switch
 - a. Remove the lock. (If any);
 - b. Push the position indicated by the arrow down (as shown in the diagram below);
 - c. Wait for it to return to OFF state.



10 Operation on LCD

10.1 Introduction of Control Panel




Figure 10-1 Control Panel

- In a normal state, the "Power", "Today" and "Battery" information will be displayed. You can press the keys to switch information.
- In an error state, the fault message and error code will be displayed, please refer to ["12.2 Troubleshooting"](#) for corresponding solutions.


Table 10-1 Definition of indicators

LED indicator	Status	Definition
 Operating	 Solid blue	The inverter is in a normal state.
	 Blue blinking	The inverter is in a waiting or checking state.
 Error	 Solid red	The inverter is in a fault state.
	 Green blinking	Both of the batteries are in an idle state.
 Battery	 Solid green	One of the batteries is in a normal state at least.
	 Green blinking	Both of the batteries are in an idle state.
	 Solid display	One of the batteries is connected normally at least.
	 Blinking	Both of the batteries are disconnected.

Table 10-2 Definition of keys


Key	Definition
 ESC key	Exit from the current interface or function
 Up key	Move the cursor to the upper part or increase the value
 Down key	Move the cursor to the lower part or decrease the value
 Enter key	Confirm the selection

10.2 Introduction of Menu Interface




There are eight submenus in the menu that can be selected for relevant setting operations.


- **System ON/OFF:** Switch on and off the inverter.
- **Mode Select:** Select the working mode of the inverter, including **Self Use**, **Feed-in Priority**, **Backup Mode**, **Manual**, **Peaking Shaving**, **TOU** and **SmartSchedule**.




- **System Status:** Display the real-time value of PV, battery, etc. Including **PV1**, **PV2**, **PV3**, **Battery 1**, **Battery 2**, **On-grid**, **EPS** and **Meter/CT**.




- **Parallel Status:** Display all the status data from master inverter when the inverters are parallel-connected.
- **History Data:** Display the history data of **On-grid**, **EPS**, **E_FEEDIN**, **E_USERDEF** and **Error Log**.




- **ARC Clear:** When it is disabled by default, the inverter will automatically clear the arc fault in five minutes for up to four consecutive times. If the arc fault happened the fifth time, manual clear is needed. For manual clear, select **Trigger** in **Arc Clear**, the inverter will clear the arc fault immediately and restart the system. Other **Arc Enable** and **Arc Self Check** please refer to "[Arc Setting](#)".



- **Setting:** Set the parameters of inverter, including **User Setting** and **Advance Setting**.




- **About:** Display the information about **Inverter**, **Battery 1**, **Battery 2** and **Internal code**.



10.3 System ON/OFF

Setting path: **Menu>System ON/OFF**


Select **ON** or **OFF** to switch on and off the inverter. The interface is displayed **OFF** by default. When you select **OFF**, the inverter stops running.



10.4 Mode Select

Selecting path: **Menu>Mode Select**


Here you can only select the working mode, i.e. Self-use mode, Feedin Priority, Backup, Peak shaving, TOU, Manual and Smart Schedule. You can choose the working modes according to your lifestyle and environment. Please refer to "2.6 Working mode" for introduction of the modes and "10.7.1 User Setting" for specific setting of each mode.




Setting TOU mode

TOU can only be set in SolaXCloud App. After setting the TOU in the App, the selected TOU mode will be displayed in TOU interface on the LCD.


- » **Min SOC:** The minimum SOC of the system.
- » **Min SOC:** Default: 10%



- » **Self-use:** Same working logic with "Self-use Mode", but it is not limited by the charging and discharging time slots. The priority of PV: Loads > Battery > Grid.
- » **Min SOC:** Default: 10%




- » **Battery Off:** The battery neither charges nor discharges. The power of PV will supply to loads or the grid. Only when the battery SOC is lower than the system (TOU) Min SOC, the battery can be charged.



- » **Peak shaving:** The working logic is that when the power consumption from the grid exceeds the set PeakLimit value, the battery is allowed to discharge power. The excess power beyond the limit is provided by the combination of photovoltaic and battery to ensure that the maximum power purchased from the grid does not exceed the set limit.

- » **Peaklimits:** Default: 1000 W




- » **Charging:** The power of PV will charge the battery as much as possible to the set SOC of Charge BAT to (%). You can set whether to Charge from grid. The default value of Charge BAT to (%) is 100%. When the battery reaches the set SOC, the surplus power will perform "Self-use Mode" or supply to the grid (based on the system setup), at this point, Charge from grid is not allowed.


- » **Charge from grid:** Default: Disable

- » **Charge BAT to:** Default: 100%

- » **Charging Power:** Default: 0000 W




- » **Discharging:** If allowed by the battery, the system outputs a specified power from the grid based on the set output percentage, controlling the power at the AC port. You need to set the RatePower (%) through Web or App when choosing Discharging mode. When the battery Discharge to (%) reaches the set SOC, the inverter performs "Self-use Mode".
- » **Rate of AC Power:** Default: 100%
- » **Discharge to:** Default: 10%
- » **Discharging Power:** Default: 0000 W



Setting Smart schedule mode

Smart schedule can only be set in SolaXCloud App. After setting the Smart schedule in the App, the selected Smart schedule mode will be displayed in Smart schedule interface on the LCD.




10.5 System Status


Displaying path: **Menu>System Status**

After entering into the **System Status** interface, the status of PV, Battery, On-grid, EPS, Meter/CT will be displayed on the LCD as follows:


- PV status: You can see information of **PV1**, **PV2** and **PV3**. Information contains input voltage, current and power of each PV. For X3-ULT-15K, 19.9K and 20K inverter, the value in PV3 is 0.




- Battery status: There will be information of **Battery1** and **Battery2** displayed here. It shows the status of each battery terminal, including the voltage, current, power, SOC, cell temperature, BMS connection status and pack status. Positive value with power means charging; negative value means discharging.




- On-grid status: Information contains the voltage, current, frequency, and output power of Grid port. The "A", "B" and "C" in **On-grid A**, **On-grid B** and **On-grid C** refers to L1, L2 and L3 respectively. The figure below will take **On-grid A** as an example. Positive value with power means power output; negative value means power input.



- EPS status: Information contains apparent power, voltage, current, active power and frequency of **EPS** port when it is disconnected from the grid. The "A", "B" and "C" in EPS A, EPS B and EPS C refers to L1, L2 and L3 respectively. The figure below will take EPS A as an example.



- Meter/CT status: Information contains feed-in power of L1, L2 and L3 detected by the connected meter or CT. Positive represents feeding electricity to the grid, negative represents drawing electricity from the grid (buying electricity).




10.6 History Data


Displaying path: **Menu>History Data**

After entering into the History Data interface, the status of **On-grid**, **EPS**, **E_Feedin**, **E_USERDEF**, **Error Log** will be displayed on the LCD as follows:


- **On-grid**: A record of the output and input electric energy of inverter from grid today and the total. (through Grid port)
 - » **Output Today**: Output electric energy of inverter today.
 - » **Output Total**: Total output electric energy since the inverter activated for the first time.
 - » **Input Today**: Input electric energy of inverter today.
 - » **Input Total**: Total input electric energy since the inverter activated for the first time.




- **EPS**: A record of the output electric energy of the inverter today and the total. when it is disconnected from grid. (through **EPS** port)



- **E_Feedin:** The total electricity fed into or taken from the grid since the inverter activated for the first time and on that day. (detected by Meter/CT)
 - » **Feedin Today:** Electricity sold to grid today.
 - » **Feedin Total:** Total electricity sold to grid since the inverter activated for the first time.
 - » **Consume Today:** Electricity bought from grid today.
 - » **Consume Total:** Total electricity bought from grid since the inverter activated for the first time.



- **E_USERDEF:** The electricity of the connected on-grid inverter today and the total.(detected by Meter 2) This function is only available when the meter 2 is connected.



- **Error Log:** Display the recent six error messages. Information contains date and time error happened, error code and error description.



10.7 Setting

Settings includes User Settings and Advanced Settings.

10.7.1 User Setting

Setting path: **Menu>Setting ("0 0 0 0 ")>User Setting**


NOTICE!

The default password for **User Setting** is "0 0 0 0".

Setting Date & Time


You can set the current date and time of the installation site.

The display format is "2023-06-16 14:00", in which the first four numbers represent the year (e.g. 2000–2099); the fifth and sixth numbers represent the month (e.g. 01–12); the seventh and the eighth numbers represent the date (e.g. 01–31). The remaining numbers represent the time.



Setting Language


This inverter provides multiple languages for customers to choose, such as English, Deutsch, francais, Polskie, Espanol, Português. The default language is English.



Setting EPS Mute

When the inverter is running in EPS Mode, you can choose whether the buzzer is turned on or not .

- Select **Yes**, the buzzer mutes. This function is turned off by default.
- Select **NO**, the buzzer will sound once every 4 seconds if the battery SOC is > EPS min. SOC. When the battery SOC is equal to EPS min SOC, the buzzer will sound with higher frequency at every 400 ms.




Setting Self Use Mode

Please refer to "2.7.1 Self-use Mode" for working logic of this mode.


- **Min SOC:** Default: 10%; range: 10%–100%
 - » The minimum SOC of the battery. The battery will not discharge power when the SOC of the battery reaches this value.



- **Charge from grid:**
 - » You can set whether to draw electricity from the grid to charge the battery during the charging period. When **Charge from grid** is set to **Enable**, the utility power is allowed to charge the battery; when it is set to **Disable**, the utility power is not allowed to charge the battery.



- **Charge battery to:** Default: 30%; range: 10%–100%
 - » Set the SOC target value for charging the battery from grid during the charging period (applicable only when the **Charge from grid** is enabled).
 - » You can set your own target value, i.e. during the charging period, the inverter will use both PV & GRID energy to charge the battery SOC to the target SOC value+5%, after the battery SOC meets the target value, if the PV energy is still sufficient (enough for load and there is excess power), the inverter will continue to use PV energy to charge the battery.



Setting Feed-in Priority

Please refer to "2.7.2 Feed-in Priority" for working logic of this mode.

- **Min SOC:** Default: 10%; range: 10%–100%
 - » The minimum SOC of the battery. The battery will not discharge power when the SOC of the battery reaches this value.



- **Charge battery to:** Default: 50%; range: 10%–100%
 - » Set the amount of SOC to charge the battery from grid (applicable only when the **Charge from grid** is enabled).
 - » You can set your own target value, i.e. during the charging period, the inverter will use both PV & GRID energy to charge the battery SOC to the target SOC value+5%, after the battery SOC meets the target value, if the PV energy is still sufficient, the surplus power will be fed into the grid.

====Feedin Priority====
>Charge battery to 50%

Setting Backup Priority

Please refer to "2.7.3 Backup Mode" for working logic of this mode.

- **Min SOC:** Default: 30%; range: 30%–100%
 - » The minimum SOC of the battery The battery will not discharge power when the SOC of the battery reaches this value.

====User Setting====
Feed-in Priority
>Backup Mode
Char&Disc Period



====Backup Mode====
>Min SoC 30%


- **Charge battery to:** Default: 50%; range: 30%–100%
 - » In this mode, the charge from grid function is turned on by default, and customers can set the target value by themselves, that is, during the charging period, the inverter will cooperate with PV&GRID to charge the battery to the target value. If the PV energy is still sufficient (enough for load and there is excess power), the inverter will continue to use PV energy to charge the battery.

====Backup Mode====
>Charge battery to 50%


Setting Char & Disc Period

Here you can set the **Forced Charge Period** and **Allowed Disc Period**. If two charging and discharging periods are needed, enable the **Function Control** to activate the **Char&DischrgPeriod2**.

- **Char&Disc Period:** You can set the charge and discharge time according to your own needs. The default time axis of the system is 24 h.
 - » **Forced Charge Period Start Time:** Time to start charging; default: 00:00; range: 00:00–23:59
 - » **Forced Charge Period End Time:** Time to stop charging; default: 00:00; range: 00:00–23:59
 - » **Allowed Disc Period Start Time:** Time allows to start discharging (The charging or discharging of the battery depends on the work mode.) default: 00:00; range: 00:00–23:59
 - » **Allowed Disc Period End Time:** Time to stop discharging; default: 23:59; range: 00:00–23:59



- **Char&Disc Period2:** The second time axis is closed by default, If two charging and discharging periods are needed, turn on the charging and discharging period 2. This period will hold the same setting logic as **Char&Disc Period**.



NOTICE!

- Charging/discharging periods apply to self-use, feed-in priority, and backup modes
- During times not set for either, the battery can charge but not discharge.
- If a period is designated as both, forced charging will occur.


Setting Peak shaving mode

Please refer to "2.7.4 Peak Shaving Mode" for working logic of this mode.

NOTICE!

- To set the parameters for the peak shaving mode, please select **Peak Shaving** in **Menu > Mode Select** in advance. Otherwise, the mode will not be displayed under the **Menu > Setting > User Setting** path.


- PeriodA:** This period allows inverter to take energy from grid to charge battery in order to have enough backup for peak shaving.
 - » **Enable:** Activate the function of **ChargeFromGrid** to allow the inverter taking grid energy to charge battery. The **ChargePowerLimits** and **MAX_SOC** will be displayed only when **ChargeFromGrid** is enabled.
 - » **ChargePowerLimits:** Default: 1000 W; range: 0-60000 W
Settable target power taken from grid. Inverter will use this target power taken from grid to charge battery.
 - » **MAX_SOC:** Default: 50%; range: 10%-100%
Inverter will take grid energy to charge battery until battery SOC reaches this value.



- PeriodB:** To set **ShavingStartTime**, **ShavingEndTime**, **PeakLimits** and **ChargeFromGrid**. **PeriodB** can be regarded as peak shaving period. This period should be set to cover load peaks. Battery will be discharged to shave load peak until battery SoC drops to Min. SoC (10% by default).
 - » **ShavingStartTime:** Default: 7:00
The battery starts discharging to shave consumption from the set time.
 - » **ShavingEndTime:** Default: 15:00
The battery stops discharging at the set time.


- » **PeakLimits:** Default:0 W, range: 0-60000 W

Once the consumption (from the power grid) reaches this value, the inverter will start shaving to keep the consumption not exceed this value.



- » **ChargeFromGrid:** Set **ChargeFromGrid** to **Enable**, to allow the inverter to take electrical power from grid to charge batteries. You need to further set **ChargePowerLimits** and **MAX_SOC** once **ChargeFromGrid** is enabled.

MAX_SOC: Inverter will take grid energy to charge battery until battery SOC reaches this value. Default: 50%; range: 10%-100%



- **PeriodD:** Same working logic with **PeriodB**, but its shaving start and end time are 19:00 and 23:00.
- **Reserved_SOC:** Default: 50%; range: 10%-100%
 - » It can be used in specific time period. In this period, inverter does not allow taking grid energy to charge battery. PV is the only way to charge battery and PV will charge the battery first. Inverter will not supply power to loads until battery SOC higher than this value in order to save enough energy for later shaving period.



Setting User Password

The default password is "0 0 0 0". You can reset the password here.

10.7.2 Advanced Setting

Setting path: **Menu>Setting>Advance Setting**

NOTICE!

- All the adjustable parameters including safety code, grid parameter, export control, etc. can be modified under the permissions of installer password. Unauthorized use of the installer password by unauthorized persons can lead to incorrect parameters being input, resulting in power generation loss or violation of local regulation.
- The initial password is 2014 which should be changed for the consideration of account security.

Setting Safety Code

NOTICE!

- The inverter cannot be connected to the grid before the safety code is correctly set. If there is any doubt about your safety code where the inverter installed, please consult your dealer or SolaX service for details.
- The setup will vary from different safety codes.

Here you can set safety code according to different countries and grid-tied standards. In addition, the inverter has an **User Defined** option which allows you to customize relevant parameters with a wider range.

There are several standards to choose from, please refer to the LCD screen on the inverter. (May be changed or added without notice)

Table 10-3 Safety code

Safety code	Country
TOR	Austria
G99	United Kingdom
TR	Denmark
EN50549-EE	Estonia
EN50549-SE	Sweden
AS 4777.2	Australia
CEI0-21	Italy
C10/26	Belgium
G100 NI	Northern Ireland
VDE4105	Germany
PEA	Thailand

For Australia, select Australia Region A/B/C in compliance with AS/NZS 4777.2. Only after the safety code setting is completed, some designated parameters in the inverter system will take effect according to the corresponding safety regulations.

Table 10-4 Region settings

Region	Australia A	Australia B	Australia C	New Zealand	
Standard Code Name	AS4777_2020_A	AS4777_2020_B	AS4777_2020_C	New Zealand	Setting Range
OV-G-V	265 V	265 V	265 V	265 V	230–300 V
OV-GV1-T	1.5 s	1.5 s	1.5 s	1.5 s	
OV-G-V2	275 V	275 V	275 V	275 V	230–300 V
OV-GV2-T	0.1 s	0.1 s	0.1 s	0.1 s	
UN-G-V1	180 V	180 V	180 V	180 V	40–230 V
UNGV1-T	10 s	10 s	10 s	10 s	
UN-G-V2	70 V	70 V	70 V	70 V	40–230 V
UNGV2-T	1.5 s	1.5 s	1.5 s	1.5 s	
OV-G-F1	52 Hz	52 Hz	55 Hz	55 Hz	50–55 Hz
OVGF1-T	0.1 s	0.1 s	0.1 s	0.1 s	
OV-G-F2	52 Hz	52 Hz	55 Hz	55 Hz	50–55 Hz
OVGF2-T	0.1 s	0.1 s	0.1 s	0.1 s	
UN-G-F1	47 Hz	47 Hz	45 Hz	45 Hz	40–50 Hz
UNGF1-T	1.5 s	1.5 s	5 s	1.5 s	
UN-G-F2	47 Hz	47 Hz	45 Hz	45 Hz	45–50 Hz
UNGF2-T	1.5 s	1.5 s	5 s	1.5 s	
Startup-T	60 s	60 s	60 s	60 s	15–1000 s
Restore-T	60 s	60 s	60 s	60 s	15–600 s
Recover-VH	253 V	253 V	253 V	253 V	
Recover-VL	205 V	205 V	205 V	198 V	
Recover-FH	50.15 Hz	50.15 Hz	50.15 Hz	50.15 Hz	
Recover-FL	47.5 Hz	47.5 Hz	47.5 Hz	47.5 Hz	
Start-VH	253 V	253 V	253 V	253 V	
Start-VL	205 V	205 V	205 V	198 V	

Region	Australia A	Australia B	Australia C	New Zealand	
Standard Code Name	AS4777_2020_A	AS4777_2020_B	AS4777_2020_C	New Zealand	Setting Range
Start-FH	50.15 Hz	50.15 Hz	50.15 Hz	50.15 Hz	
Start-FL	47.5 Hz	47.5 Hz	47.5 Hz	47.5 Hz	

Setting Grid parameters

The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations. Please refer to the actual contents displayed on the LCD screen on the inverter.

```
====Grid Parameters====
>Overvoltage
Undervoltage
OverFreq_L1
```

Setting Charger

The inverter is compatible with lithium-ion battery. You can set the charge & discharge parameters of battery. The interface for this setting item will be different when connected to a single battery and when connected to dual batteries.


- **Max Charge:** Maximum charging current of battery
- **Max Discharge:** Maximum discharging current of battery
- **Charger upper limit:** The maximum battery SOC when charging. Default: 100%, range: 10%-100%
 - » Single battery connection:

```
=====Charger=====
>Max Charge
Current: 60.0A
```

```
=====Charger=====
>Max DisCharge
Current: 60.0A
```

```
=====Charger=====
>Charger upper limit 100%
```

» Dual battery connection:



Setting Export Control

This function allows the inverter to control power output to the grid. The user value set must be less than the maximum value. If the user does not want to supply power to the grid, set **User Value** to "0".

```
====Export Control====
>Soft Limit value
30000W
```

NOTICE!

- Under Safety Code AS4777, **Export Control** is in the path of **Advance Setting> AS4777 Setting**. You can set the **Soft Limit** and **Hard Limit** of **Export Control** to control the power output to grid. Please refer to section AS4777 Setting for details.

Meter/CT Setting

CT or electricity meter is needed to connect with the inverter. Meter is set by default.


NOTICE!

- If the user has other power generation equipment (such as inverter) at home and wants to monitor both, the inverter provides Meter 2 communication function to monitor the power generation equipment.

- Select and enter the **Meter/CT Setting** according the setting path.
- Set the address and direction of Meter/CT:
 - » Case 1: Only CT is connected for the series inverter. No power generation equipment in the whole system. Please activate the CT selection and choose the supported CT type. You can check the connection status in **Meter/CT Check**.




- » Case 2: Only Meter 1 is connected for the series inverter. No power generation equipment in the whole system. Please activate the meter 1 selection and set the meter address and direction. You can check the connection status in **Meter/CT Check**. SolaX Meter is supported. If SolaX Meter is used, the inverter will automatically recognise it and the **Meter1 config** related settings will appear.



NOTICE!

- CT and meter 1 can not be used simultaneously.

- » Case 3: CT and Meter 2 are connected. (CT for SolaX Hybrid inverter, Meter 2 for another power generation equipment or CT for another power generation equipment, Meter 2 for SolaX Hybrid inverter) For CT setting, please refer to Case 1. For meter 2 setting, please set the address and direction of Meter 2 based on actual connection. You can check the connection status in **Meter/CT Check**. SolaXMeter is supported. If SolaXMeter is used, the inverter will automatically recognise it and the **Meter2 config** related settings will appear.



- » Case 4: Meter 1 and Meter 2 are connected. (Meter 1 for SolaX Hybrid inverter, Meter 2 for another power generation equipment or Meter 1 for another power generation equipment, Meter 2 for SolaX Hybrid inverter). Please refer to Case 2 for Meter 1 setting and Case 3 for Meter 2 setting. You can check the connection status in **Meter/CT Check**.

Setting Self Test (only for CEI 0-21)

The self test function allows users to test the following items: **Full Test**, **Ovp(59.S2) test**, **Uvp (s1) test**, **Uvp (27. s2) test**, **Ofp (81> .S1) test**, **Ufp (81 <.S1) test**, **Ufp (81> .S2) test**, **Ufp (81 <.S2) test**, **Ovp10 (59. s1) test**.

In the **Self Test** interface, the user can select **All Test** or a single test item for testing. All tests take about 6 minutes. And it will display **Success**. For a single test item, it takes about a few seconds or minutes.

Before testing, make sure that the inverter is connected to the grid. Click **Test Report** to view the test results of all items.


```

=====Self Test=====
>All Test
Test Report
Ovp (59.S2) test
  
```

Setting GMPPT


You can set the shadow tracking speed with four options, which are **Off**, **Low**, **Middle**, and **High**. This function is off by default.

- **Off**: Switch off the shadow tracking function.
- **Low**: Scan the shadow every four hours.
- **Middle**: Scan the shadow every three hours.
- **High**: Scan the shadow per hour.



Setting Modbus

You can set the address and select the Baud rate of the external communication protocol for communicating with external equipment.



Setting Power Factor

The default value is the specified value under the current safety regulations. The contents will be displayed according to the requirements of local laws and regulations. Please refer to local grid requirements.




Table 10-5 Items under Power Factor

Off	
Over Excited	PF Value
Under Excited	PF Value

Curve	P1 PF
	P2 PF
	P3 PF
	P4 PF
	Power 1
	Power 2
	Power 3
Curve	Power 4
	PflockInPoint
	PflockOutPoint
	3Tua
	Select
Q(u)	SetQuPower1
	SetQuPower2
	SetQuPower3
	SetQuPower4
	QuRespondV1
	QuRespondV2
Q(u)	QuRespondV3
	QuRespondV4
	K
	3Tua
	QuDelayTimer
	QuLockEn
Fixed Q Power	Q Power

- Reactive power control, reactive power standard curve $\cos \varphi = f(P)$
 - For VDE ARN 4105, the curve $\cos \varphi = f(P)$ should refer to curve A. The set default value is shown in curve A.




Figure 10-2 Curve A

*) If P_{max} of the inverter ≤ 4.6 kW, the Power Factor is 0.95 at 1.0 power; if P_{max} of the inverter > 4.6 kW, the Power Factor is 0.90 at 1.0 power.

- For TOR, the curve $\cos \varphi = f(P)$ should be curve B. The set default value is shown in curve B.




Figure 10-3 Curve B

*) Depend on the required Q capacity

- » For CEI 0-21, the default value of PFLockInPoint is 1.05. When $V_{ac} > 1.05V_n$, $P_{ac} > 0.2 P_n$, curve $\cos \varphi = f(P)$ corresponds to curve C.




Figure 10-4 Curve C

- Reactive power control, reactive power standard curve $Q = f(V)$





Figure 10-5 Curve $Q = f(V)$

Setting Pu Function

(Applicable to specific countries, please refer to local grid requirements.)

The Pu function is a volt-watt response mode required by certain national standards such as AS/NZS 4777.2. This function can control the active power of the inverter according to the grid voltage. You can set **Response Voltage**, **3Tau**, **PuPower**, **3Tau_Charge** and **Pu Type**.

The items in the **P(u) Function** interface will be adjusted in accordance with the local safety requirements and law regulations, casual modification is prohibited.



For AS/NZS 4777.2, the curve required for the volt-watt mode can be referred to the below curve.





Figure 10-6 Curve for P(u)

Setting FVRT function

PVRT consists of HVRT (High Voltage Ride Through) and LVRT (Low Voltage Ride Through). With PVRT function, the series inverter can ensure continuous operation without disconnecting from the grid within a certain range of voltage sudden rise and drop in a certain time interval.

- **Enable:** Enable the FVRT function
- **VacUpper:** The voltage for high voltage ride through
- **VacLower:** The voltage for low voltage ride through



Setting Power Limit

Here you can set the rated power by percentage.

The percentage of rated output power is used as the actual output power.

Proportion: Default: 1.00; range: 0.00–1.10

(For 30 kW inverter, the proportion can only be set to 0.00–1.00 and for other models of this series inverter, the proportion can be set to 0.00–1.10.)

```
====Power Limit====
Proportion
1.00
```

Setting DRM function (Applicable to AS4777)

The DRM Function is a demand response method required by the AS4777 standard and is only applicable to Australia and New Zealand.

The function is enabled by default.

```
====DRM Function====
>Func Select
Enable
```

Setting Main Breaker Limit

Due to power limit, the current of Meter or CT must be abide by the utility's requirements. You can set the corresponding amperage according to the utility's requirements. Failure to set the current may cause a circuit breaker fault of main switchboard, thus affecting the charging and discharging of battery.

The default value is 250 A, range: 0–1000 A

```
==Main Breaker Limit==
>Current
100 A
```

Setting Phase Unbalanced

This function controls the distribution of AC output power. **Disable** is the default setting. X3-ULT-10K-GLV and X3-ULT-15K-GLV do not support this function.

- **Enable** mode: Each phase of power will be independently outputted according to the corresponding loads connected with each phase.




Figure 10-7 Phase Unbalanced enabled

- **Disable** mode: Three-phase power balanced output, with equal power in each phase. The total power output is determined by the total load power of the three phases.





Figure 10-8 Phase Unbalanced disabled


Setting EPS Setting

Select and enter **EPS Setting** interface and set **Frequency**, **Min SOC** and **Min ESC SOC**.

- **Frequency:** Default: 50Hz. Output frequency of EPS
- **Min SOC:** Default: 10%, range: 10%-100%
 - » If the battery SOC is lower than the **Min SOC**, the inverter will prompt **BatPowerLow** and turn off if there is no PV input.
- **Min ESC SOC:** Default: 30%, range: 15%-100%
 - » In EPS mode, the minimum SOC required for re-entry EPS mode after **BatPowerLow** prompted. When the battery SOC reaches the **Min ESC SOC** through charging from PV, the inverter will automatically enter EPS mode from EPS Waiting mode.



- **Super-Backup:** To enable the **Super-Backup** mode and allow only PV without battery to enter EPS. **Disable** is the default setting.



For three-phase inverters, the output power of EPS ports is restricted to half (50%) of the nominal output power of EPS ports (without battery) total phase. For more details in the table below.

EPS output (Without battery)	X3-ULT-10K- GLV	X3-ULT-15KP/ X3-ULT-15K/ X3-ULT-15K- GLV	X3-ULT-19.9K	X3-ULT-20K/ X3-ULT-20KP	X3-ULT-25K/ X3-ULT-25KW	X3-ULT-30K
Normal output power (W)	5000	7500	9999	10000	12500	15000
Peak apparent power (VA) 130% overload	6500	9750	12999	13000	16250	19500


Setting AS4777 Setting

The function of **AS4777 Setting** is only activated when the **Safety Code** is set to AS4777 and New Zealand, which is only applicable to Australia and New Zealand.

- a. Select and enter **AS4777 Setting** in **Advance Settings** interface. You will see **Export Control** (for active power output control) and **General Control** (for apparent power output control).

```
====AS4777 Setting====
>Export Control
  General Control
```

- b. Set the **Soft Limit** value and **Hard Limit** value for Export Control and General Control. The figure below will take the setup of Export Control as an example.



NOTICE!

- **Soft Limit:** Control the output value to grid within the set **Soft Limit Value**.
- **Hard Limit:** If the actual output value reaches the set **Hard Limit Value**, the system will automatically disconnect from grid and prompt error message on the LCD.

Arc Setting

The inverter has arc detection function, which detects the arcing of the DC side and cuts the circuit in time to protect the user and the electrical system. The arc module of the series inverter meets the requirements of IEC 63027.

The user can do settings about **ARC Enable** and **ARC Self Check**.

- **ARC Enable:** Select **Enable** in **ARC Enable**, the inverter will report **ARC Test Fault** when faults are detected. When it is disabled, there won't be any reports even when faults occurred, and the faults will be cleared simultaneously

```
====ARC Enable====
>ARC Enable:
  Disable
```

- **ARC Self Check:** Select Enable in **ARC Self Check**, the inverter will self-check whether the arc detection function is working normally and return to **NULL** after the checking process is completed.

```

==ARC Self Check==
>ARC Self Check:

NULL

```

NOTICE!

- **ARC Self Check** should be done when the inverter is in normal state and the current is greater than 1.5 A. If an **ARC Test Success** is reported, the arc detection function is working normally.

Setting ExternalGen

Refer to the "[15.1 Generator Application](#)" for reference.

Reset

Here you can reset value of Error Log, Meter/CT, INV Energy, Wi-Fi and restore to the factory set.

- **Reset Error Log**

```

=====Reset=====
>Reset Error Log
Reset Meter/CT_1
Reset Meter/CT_2

```



```

====Reset Error Log====
>Reset
> Yes <

```

- **Reset Meter/CT_1 or Meter/CT_2**

» **Energy:** Power Reset Zero.

» **Software:** Meter reset and restart, valid when using SolaXMeter.

```

=====Reset=====
>Reset Error Log
>Reset Meter/CT_1
Reset Meter/CT_2

```



```

====Reset Meter/CT_1====
>Energy
Software

```

- **Reset INV Energy**

```

=====Reset=====
Reset Meter/CT_2
>Reset INV Energy
Reset Wi-Fi

```




```


====Reset INV Energy====
>Reset
> Yes <

```

- **Reset Wi-Fi**




- **Factory Reset**




Setting Battery Heating

This function is disabled by default and is only valid when the battery has the heating function. You can enable **Battery Heating** function to make the battery heated. And set the heating period. Only supports on-grid heating.

- Single battery connection:
 - Enable the **Battery Heating** function.




- Select the heat level. Three level can be set: Low/Middle/High.



- Set the heating start time and end time for the battery. Two heating periods can be set.



- Dual battery connection:
 - Select the battery, battery1 or battery2.



- b. Select the heat level. Three level can be set.

```

====Battery Heating====
>Heat Level:
  > Low  <
  
```

- c. Enable the **Battery Heating** function.

```

====Battery1====
>Func Select
  > Enable  <
  
```

- d. Set the heating start time and end time for the battery. Two heating periods can be set.

```

====Battery1====
>Heating Period 1
  Start Time
    00:00
  
```

```

====Battery1====
>Heating Period 1
  End Time
    00:00
  
```

```

====Battery1====
>Heating Period 2
  Start Time
    00:00
  
```

```

====Battery1====
>Heating Period 2
  End Time
    00:00
  
```

NOTICE!

- If the ambient temperature is extremely low, turning on battery heating will consume a significant amount of electrical energy.

Setting Extend BAT FUNC

This function allows for the extension of battery modules, such as adding a new battery module to an existing system. It is only applicable and functional in on-grid mode and cannot be used in EPS mode. In on-grid mode, enabling this function will make the inverter to charge or discharge the battery SOC to approximately 38%. This function will turn to **Disable** automatically after 48 hours this function enabled.

```

====Extend BAT FUNC====
Function Control
  > Enable  <
  
```

Setting HotStandby Setting

This function is mainly to reduce the energy losses of the system when the power of load is very low.

- **Enable:** When the power of load is very low and other conditions for entering hot standby are met, the inverter will enter **HotStandby** status to reduce system losses.
- **Disabled:** Even when the power of load is very low and other conditions for entering hot standby are met, the inverter will not enter **HotStandby** status and continue to output power to the load. It is disabled by default.

```
===HotStandby Setting===  
Function Control  
> Enable <
```

Setting Pgrid Bias

This function is disabled by default.

When the inverter has no power output:

- Check the **Meter/CT** value in **Menu>System Status>Meter/CT** when the function is disabled.
- If the **Meter/CT** displayed in **System Status** is negative value, please select **Grid** for **Pgrid Bias** to discharge power to the mains. If the **Meter/CT** displayed in **System Status** is positive value, please select **INV** for **Pgrid Bias** to take power from the mains.

```
=====Pgrid Bias=====  
> Grid <
```

- Set the Bias power value for power extraction/feeding.

```
=====Pgrid Bias=====  
> BiasPower  
40 W
```

Setting Internal485

You can communicate with other SolaX equipment through **Internal485**.

- Select and enter **Internal485** interface;
- Select the equipment to be connected and set the corresponding Baud Rate and Address. Take EV Charger as an example, The default baud rate is 9600.

```
=====Internal485=====  
>Function Control  
EV Charger
```



```
=====Internal485=====  
>Baud Rate  
9600
```



```
=====Internal485=====  
>EV Charger Addr:  
70
```


NOTICE!

- When two equipments need to be connected at the same time, the Baud Rate and address of the two equipments shall be set to the same.

- c. Check the connection status.

```
====Internal485====
>EV Charger COM STAT
    Connected
```

Battery Charge EVC

You can set **Enable** to allow the battery to discharge energy to EV Charger. When you set to **Disable**, battery discharging energy to EV Charger is not allowed.

```
===Battery charge EVC===
>Function Control
    Enable
```

Advanced Password

You can reset the advanced password here.

Shut Down

This function enables remote control of the inverter switch status by disconnecting or connecting the external switch connected to the inverter.

- Enable/Disable:** Whether remote control is enabled.

```
===Shut Down===
>DI1&DI2
    Enable
```

- NO/NC:** NO (Always on) by default.
 - » **NO** (Always on): When the switch is disconnected, the inverter works normally, and when the switch is connected, the inverter shuts down.
 - » **NC** (Always closed): When the switch is connected, the inverter works normally, and when the switch is disconnected, the inverter shuts down.

```
===Shut Down===
>Func Select:
    NO
```

- If the inverter is connected externally to an NS protection device to disconnect the inverter when necessary to protect the system, operate as follows:

- » When the Inverter is Used Standalone:

Connect the dry contact to DI1 or DI2 of COM2, with pins Pin3/4 or Pin5/6, and enable **ShutDown > Enable > NC**.




Figure 10-9 Connection diagram for NS Protection

- » When Running in Parallel:

The external NS protection device only needs to be connected to the Master inverter, with settings the same as those for standalone use.




Figure 10-10 Connection diagram for NS Protection in parallel

10.8 About

Displaying path: **Menu > About**

Here shows the basic information of the inverter, battery, meter and internal code. After entering into the About interface, you can check those information.

- Inverter
 - » Model Name, Inverter SN, Register SN, ARM Version, DSP version, On-grid Runtime, EPS Runtime.
- Battery 1 and Battery 2
 - » BatBrand, Bat_M SN (SN of BMS), Bat_PS1 SN (SN of battery module 1), Bat_PS2 SN (SN of battery module 2), Bat_PS3 SN (SN of battery module 3), Bat_PS4 SN (SN of battery module 4), Battery M Version (software version of BMS) and Battery S version (software version of battery module).
 - » If multiple clusters of batteries are connected in parallel, cluster will also be displayed.
- Internal Code
 - » Internal code of inverter, battery 1 and battery 2.
- Meter_1 Info and Meter_2 Info
 - » Meter_Type, Software, SN, Hardware.

11 Operation on SolaXCloud

11.1 Introduction of SolaXCloud App

SolaXCloud provides a platform for you to monitor the device data and set the device remotely. The inverter connects the system through Pocket Wi-Fi, Pocket LAN, Pocket 4G, or Ethernet direct connection, and upload the operation data to SolaXCloud every 5 minutes. You can log in to your user account at any time through a personal computer, IOS or Android device to view real-time monitoring data or historical data, and perform remote settings as needed.

11.2 Operation Guide on SolaXCloud App

11.2.1 Downloading and Installing App

Download and install the SolaXCloud app. You can download the app by the following methods.

- Scan the QR code below.
- Find and scan the QR codes at the button right of the login page of www.solaxcloud.com.
- Search with the key word SolaXCloud on the App Store or Google Play.



Figure 11-1 QR code

11.2.2 Operation on the SolaXCloud App

For instructions on operations, see the online documents on the SolaXCloud app.




Figure 11-2 App guide on SolaXCloud

NOTICE!

- The screen shots in this chapter correspond to the SolaXCloud app V6.0.0, which might change with version updates and should be subject to the actual situations.

11.3 Operation Guide on SolaXCloud Web

Open a browser and enter www.solaxcloud.com to complete registration, login, add site and other related operations according to the guidelines of user guide.




Figure 11-3 Web guide on SolaXCloud

NOTICE!

- The user interface might change with version updates and should be subject to the actual situations.

12 Troubleshooting and Maintenance

12.1 Power Off

- Turn off the system by **System ON/OFF** on LCD screen.
- Switch off the battery or the load-break switch of the battery (see documentation of the battery manufacturer).
- Turn off the AC switch between the inverter and the power grid.
- Set the DC switch to "OFF".



WARNING!

- After the inverter powers off, there will still be the remaining electricity and heat which may cause electric shocks and body burns. Please wear personal protective equipment (PPE) and begin servicing the inverter five minutes after power off.

12.2 Troubleshooting

This section contains information and procedures for resolving possible problems with the inverter, and provides the troubleshooting tips to identify and solve most problems that may occur. Please check the warning or fault information on the system control panel or on the App and read the suggested solutions below when error occurs. Contact SolaX Customer Service for further assistance. Please be prepared to describe the details of your system installation and provide the model and serial number of the inverter.

Table 12-1 Troubleshooting list

Error Code	Fault	Descriptions and Diagnosis
IE 01	TZ Protect Fault	Overcurrent fault. - Wait for a while to check if it returns to normal. - Disconnect PV+ PV- and batteries, reconnect. - If the system is in off-grid state, check if the power of EPS loads exceeds the maximum limit of the system or exceeds the current power supply of battery. - If the system fails to restore to its normal state, please contact SolaX for help.
IE 02	Grid Lost Fault	- Check the grid connection status - Or contact SolaX for help.

Error Code	Fault	Descriptions and Diagnosis
IE 03	Grid Volt Fault	Power grid voltage overrun • Wait a moment, if the utility returns to normal, the system will reconnect. • Please check if the grid voltage is within normal range. • Or contact SolaX for help.
IE 04	Grid FreqFault	Grid overfrequency • Wait a moment, If the utility returns to normal, the system reconnects. • Or contact SolaX for help.
IE 05	PV Volt Fault	PV overvoltage • Check the output voltage of the PV panel. • Check if the DC switch is OFF. • Or contact SolaX for help.
IE 06	Bus Volt Fault	• Press the ESC key to restart the inverter. • Check if the PV input open circuit voltage is in the normal range. • Check if the power of half-wave load exceeds the system limit. • Or contact SolaX for help.
IE 07	Bat Volt Fault	Battery voltage fault • Check if the battery input voltage is within normal range • Or contact SolaX for help.
IE 08	AC10mins Volt	Grid voltage out of range in the last 10 minutes. • The system will return to normal if the grid returns to normal. • Or contact SolaX for help.
IE 09	DCI OCP Fault	DCI overcurrent protection fault. • Wait for a while to check if it's back to normal. • Or contact SolaX for help.
IE 10	DCV OVP Fault	DCV EPS(Off-grid) overvoltage protection fault. • Wait for a while to check if it's back to normal. • Or contact SolaX for help.
IE 11	SW OCP Fault	Software detection of overcurrent Fault. • Wait for a while to check if it's back to normal. • Shut down photovoltaic, battery and grid connections. • Or contact SolaX for help.

Error Code	Fault	Descriptions and Diagnosis
IE 12	RC OCP Fault	Overcurrent protection fault. • Check the impedance of DC input and AC output. • Wait for a while to check if it's back to normal. • Or contact SolaX for help.
IE 13	Isolation Fault	Insulation fault or earth fault is normally caused by insulation issues. • Please check the wire insulation for damage. • Wait for a while to check if it's back to normal. • Or contact SolaX for help.
IE 14	Temp Over Fault	Temperature out of range • Check if the ambient temperature exceeds the limit. • Or contact SolaX for help.
IE 15	Bat Con Dir Fault	• Battery direction fault • Check if the battery lines are connected in the opposite direction. • Or ask for help from the installer if it can not return to normal.
IE 16	EPS Overload Fault	EPS(Off-grid) overload fault • Shut down the high-power device and press the ESC key to restart the inverter. • Or contact SolaX for help if it can not return to normal.
IE 17	Overload Fault	On-grid mode overload fault • Shut down the high-power device and press the ESC key to restart the inverter. • Or contact SolaX for help if it can not return to normal.
IE 18	BatPowerLow	Bat Power Low • Shut down the high-power device and press the ESC key to restart the inverter. • Please charge the battery to a level higher than the protection capacity or protection voltage.
IE 19	BMS Lost	Battery communication lost • Check that the communication cable between the battery and the inverter are properly connected. • Or contact SolaX for help if it can not return to normal.
IE 20	Fan Fault	Fan Fault • Check for any foreign matter that may have caused the fan not to function properly. • Or contact SolaX for help if it can not return to normal.

Error Code	Fault	Descriptions and Diagnosis
IE 21	Low TempFault	Low temperature fault. • Check if the ambient temperature is too low. • Or contact SolaX for help if it can not return to normal.
IE 22	ParallelFault	Parallel Fault • Check the communication and earth cable connection and matching resistor settings. • Or contact SolaX for help if it can not return to normal.
IE 23	HardLimitFault	HardLimitFault • Check the power value set in the HardLimit setting, increase the value larger if needed. • Or contact SolaX for help if it can not return to normal.
IE 24	CTMeterConFault	CT Meter ConFault • Check if the CT or meter is well connected. • Or contact SolaX for help if it can not return to normal.
IE 25	InterComFault	Inter_Com_Fault • Restart the inverter. • Or contact SolaX for help if it can not return to normal.
IE 26	INVR EEPROM	Inverter EEPROM Fault. • Shut down photovoltaic, battery and grid, reconnect. • Or contact SolaX for help if it can not return to normal.
IE 27	RCD Fault	Residual Current Device fault • Check the impedance of DC input and AC output. • Disconnect PV + PV - and batteries, reconnect. • Or contact SolaX for help if it can not return to normal.
IE 28	Grid Relay Fault	Electrical relay fault • Disconnect PV+ ,PV- grid and batteries and reconnect. • Or contact SolaX for help if it can not return to normal.
IE 29	EPS Relay Fault	EPS relay fault • Disconnect PV+ ,PV- , grid and batteries and reconnect. • Or contact SolaX for help if it can not return to normal.

Error Code	Fault	Descriptions and Diagnosis
IE 30	PV ConnDirFault	PV direction fault - Check if the PV input lines are connected in the opposite direction. - Or contact SolaX for help if it can not return to normal.
IE 31	Battery Relay	Charge relay fault - Press the ESC key to restart the inverter. - Or contact SolaX for help if it can not return to normal.
IE 32	Earth Relay	EPS(Off-grid) earth relay fault - Press the ESC key to restart the inverter. - Or contact SolaX for help if it can not return to normal.
IE 33	Arc Fault	Check the wiring, if there is no abnormality in the wiring, then contact SolaX for help if it can not return to normal.
IE 100	PowerTypeFault	Power type fault - Upgrade the software and press the ESC key to restart the inverter. - Or contact SolaX for help if it can not return to normal.
IE 102	Mgr Eeprom Fault	Manager EEPROM Fault. - Shut down photovoltaic ,battery and grid, and then reconnect. - Or contact SolaX for help if it can not return to normal.
IE 104	Smart Ctrl Fault	Smart Ctrl Fault - Check whether the Smart Ctrl Addr and Baud rate setting on the inverter matches the address and baud rate on the DataHub. - Check whether the communication connection is correct, there is no wrong connection or disconnection.
IE 109	Meter Fault	Meter Fault - Check if the meter is working properly - Or contact SolaX for help if it can not return to normal.
IE 110	BypassRelayFlt	Bypass relay fault - Press the ESC key to restart the inverter. - Or contact SolaX for help if it can not return to normal.

Error Code	Fault	Descriptions and Diagnosis
IE111	FAN3 Fault	FAN3 Fault • Check if the foreign objects stuck in the fan. • Or contact SolaX for help.
IE 112	ARMParaComFlt	ARM Parameter Communication fault • Check that the communication cables of inverters are well connected and the baud rate of COMM setting of inverters are the same. • Or contact SolaX for help if it can not return to normal.
IE 113	FAN1 Fault	FAN1 Fault • Check if the foreign objects stuck in the fan. • Or contact SolaX for help.
IE114	FAN2 Fault	FAN2 Fault • Check if the foreign objects stuck in the fan. • Or contact SolaX for help.
IE115	20305COM_Fault	• Check if there is any instruction issued from the Australian Grid platform. • Check whether there is any abnormality in the dongle.
BE 01	BMS1_ExtErr	Battery Error - External Communication Fault • Please contact SolaX for help.
	BMS2_ExtErr	
BE 02	BMS1_IntErr	Battery Error - Internal Communication Fault • Please contact SolaX for help.
	BMS2_IntErr	
BE 03	BMS1_OverVolt	Over voltage in battery system • Please contact SolaX for help.
	BMS2_OverVolt	
BE 04	BMS1_LowVolt	Low voltage in battery system • Please contact SolaX for help.
	BMS2_LowVolt	
BE 05	BMS1_ChargeOCP	Battery fault - over charge fault • Please contact SolaX for help.
	BMS2_ChargeOCP	
BE 06	DischargeOCP1	Battery fault-discharge over current fault • Please contact SolaX for help.
	DischargeOCP2	
BE 07	BMS1_TemHigh	Over temperature in battery system • Please contact SolaX for help.
	BMS2_TemHigh	
BE 08	BMS1_TempLow	Battery temperature sensor malfunction • Please contact SolaX for help.
	BMS2_TempLow	

Error Code	Fault	Descriptions and Diagnosis
BE 09	CellImbalance1	Battery Unbalanced Fault • Please contact SolaX for help.
	CellImbalance2	
BE 10	BMS1_Hardware	Battery hardware protection fault • Please contact SolaX for help.
	BMS2_Hardware	
BE 11	BMS1_Circuit	Battery circuit fault • Restart the battery. • Please contact SolaX for help.
	BMS2_Circuit	
BE 12	BMS1_ISO_Fault	Battery insulation fault • Check that the battery is properly grounded and restart the battery. • Please contact SolaX for help
	BMS2_ISO_Fault	
BE 13	BMS1_VolSen	Battery voltage sensor fault • Please contact SolaX for help
	BMS2_VolSen	
BE 14	BMS1_TempSen	Temperature sensor fault • Restart the battery. • Please contact SolaX for help.
	BMS2_TempSen	
BE 15	BMS1_CurSen	Battery current sensor fault • Please contact SolaX for help.
	BMS2_CurSen	
BE 16	BMS1_Relay	Battery relay fault • Please contact SolaX for help.
	BMS2_Relay	
BE 17	TypeUnmatched1	Battery type fault • Upgrade the battery BMS software. • Please contact SolaX for help.
	TypeUnmatched2	
BE 18	Ver Unmatched1	Battery version mismatch fault • Upgrade the battery BMS software. • Please contact SolaX for help.
	Ver Unmatched2	
BE 19	MFR Unmatched1	Battery manufacturer mismatch fault • Upgrade the battery BMS software. • Please contact SolaX for help.
	MFR Unmatched2	
BE 20	SW Unmatched1	Battery hardware and software mismatch fault • Upgrade the battery BMS software. • Please contact SolaX for help.
	SW Unmatched2	
BE 21	M&S Unmatched1	Battery master slave control mismatch fault • Upgrade the battery BMS software. • Please contact SolaX for help.
	M&S Unmatched2	

Error Code	Fault	Descriptions and Diagnosis
BE 22	CR_NORespond1	Battery charging request no respond
	CR_NORespond2	• Upgrade the battery BMS software. • Please contact SolaX for help.
BE 23	BMS1 SW Protect	Battery slave software protection failure
	BMS2 SW Protect	• Upgrade the battery BMS software. • Please contact SolaX for help.
BE 24	BMS1 536 Fault	Battery discharge over current fault
	BMS2 536 Fault	• Please contact SolaX for help.
BE 25	BMS1 SelfCheck	Over temperature in battery system
	BMS2 SelfCheck	• Please contact SolaX for help.
BE 26	BMS1 TempDiff	Battery temperature sensor malfunction
	BMS2 TempDiff	• Please contact SolaX for help.
BE 27	BMS1_BreakFault	Battery unbalanced Fault
	BMS2_BreakFault	• Please contact SolaX for help.
BE 28	BMS1_FlashFault	Battery hardware protection failure
	BMS2_FlashFault	• Please contact SolaX for help.
BE 29	BMS1_Precharge	Battery precharge fault
	BMS2_Precharge	• Please contact SolaX for help.
BE 30	AirSwitchBreak1	Battery air switch fault
	AirSwitchBreak2	• Check if the battery breaker is off. • Please contact SolaX for help.
BE 31	ClusterCntMIS1	Battery air switch fault
	ClusterCntMIS2	• Check if the battery breaker is off. • Please contact SolaX for help.
BE 32	ClusterComAddr1	Battery air switch fault
	ClusterComAddr2	• Check if the battery breaker is off. • Please contact SolaX for help.
BE 33	BMS1_UCellOver	Battery cell overvoltage
	BMS2_UCellOver	• Please contact SolaX for help.
BE 34	BMS1_UCellLow	Battery cell undervoltage
	BMS2_UCellLow	• Please contact SolaX for help.
BE 35	BMS1_SysFault	Battery system fault
	BMS2_SysFault	• Check if the battery breaker is off. • Please contact SolaX for help.

Error Code	Fault	Descriptions and Diagnosis
BE 36	BMS1_LineFault	• Please contact SolaX for help.
	BMS2_LineFault	
BE 37	BMS1_LinkerTemp	• Please contact SolaX for help.
	BMS2_LinkerTemp	
BE 38	BMS1_BatLinker	• Please contact SolaX for help.
	BMS2_BatLinker	
BE 39	BMS1_FanError	• Please contact SolaX for help.
	BMS2_FanError	
BE 40	BMS1_FireFault	• Please contact SolaX for help.
	BMS2_FireFault	
BE 41	BMS1_MSDFault	• Please contact SolaX for help.
	BMS2_MSDFault	
IBE 01	BMS1 LOST	BMS communication loss fault • Please contact SolaX for help.
IBE 02	BMS2 LOST	BMS communication loss fault • Please contact SolaX for help.
/	Screen not on	• Check if the inverter correctly and normally connected to PV, battery or grid. • Contact SolaX for help if the inverter is connected correctly.
/	Abnormal sound on fan	• Check if there is foreign objects stuck in the fan. • Contact SolaX for help.
/	Screen on but no content display	• Contact SolaX for help.
/	LCD screen stuck in Wait state	Check if the input voltage of battery or PV is greater than 180 V. • If it meets the requirement, contact SolaX for help. • If the input voltage of battery or PV is less than 180 V, check the corresponding connection.
/	No readings after CT connection	• Check if CT is correctly clipped on the L wire • Check if the arrow on the CT points at Grid. • Contact SolaX for help if it can not return to normal.

Error Code	Fault	Descriptions and Diagnosis
/	No readings on Load (on App or Web)	• Check if the load is connected correctly. • Check if the power of load on the LCD screen displays normally. • Check if the monitoring module works normally. • Contact SolaX for help if it can not return to normal.
/	No readings on Grid (on App or Web)	• Check if the grid connection is normal. • Check if the grid parameter on the LCD screen displays normally. • Check if the monitoring module works normally. • Contact SolaX for help if it can not return to normal.
/	No readings on battery (on App or Web)	• Check if the battery is connected correctly. • Check if the battery parameter on the LCD screen displays normally. • Check if the monitoring module works normally. • Contact SolaX for help if it can not return to normal.
/	No Feedin data (on App or Web)	• Check if the meter/CT is connected correctly. • Check if the meter/CT parameter on the LCD screen displays normally. • Check if the monitoring module works normally. • Contact SolaX for help if it can not return to normal.
/	No data on App or Web	• Check if the monitoring module works normally. • Contact SolaX for help.
/	No display on meter after power on	• If the meter connection is abnormal, reconnect them according to the wiring diagrams. • Wait for the grid voltage to restore. • Contact SolaX for help if it can not return to normal.
/	Abnormal electrical data on meter	• If the wiring is incorrect, reconnect them based on the wiring diagrams. • Set the voltage and current ratio according to the setting steps of meter user manual. • Contact SolaX for help if it can not return to normal.

12.3 Meter/CT Fault

Table 12-1 Troubleshooting list

Error Code	Fault
0	CT not connected on Phase A.
1	Phase A has two CTs connected, or a CT connected to Neutral (N) phase.
2	CT1 is simultaneously on Phase A and Phase B.
3	CT2 is simultaneously on Phase A and Phase B.
4	CT3 is simultaneously on Phase A and Phase B.
5	CT not connected on Phase B.
6	Phase B has two CTs connected, or a CT connected to Neutral (N) phase.
7	CT1 is simultaneously on Phase A and Phase C.
8	CT2 is connected to Phase A, while CT1 is simultaneously connected to Phase B and Phase C.
9	CT3 is connected to Phase A, while CT1 is simultaneously connected to Phase B and Phase C.
10	CT2 is simultaneously connected to Phase A and Phase C.
11	CT1 is connected to Phase A, while CT2 is simultaneously connected to Phase B and Phase C.
12	CT3 is connected to Phase A, while CT2 is simultaneously connected to Phase B and Phase C.
13	CT3 is simultaneously on Phase A and Phase C.
14	CT1 is connected to Phase A, while CT3 is simultaneously connected to Phase B and Phase C.
15	CT2 is connected to Phase A, while CT3 is simultaneously connected to Phase B and Phase C.
16	CT not connected on Phase C.
17	Phase C has two CTs connected, or a CT connected to Neutral (N) phase.
18	No reactive power detected on Phase A after adjusting the CT sequence.
19	No reactive power detected on Phase B after adjusting the CT sequence.
20	No reactive power detected on Phase C after adjusting the CT sequence.
21–31	Reserved
32	DSP has no power or DSP has no program.

NOTICE!

- If no corresponding installation errors are found after self inspection, and when inverter is not producing, please check whether the readings of the three phases in **Status>Meter/CT** on the inverter screen match the actual situation. If there are no problems, please disable the **Installation Check** and **Cyclic Check** in the **Meter/CT setting>Meter/CT** check or contact SolaX technical support.

12.4 Maintenance

Regular maintenance is required for the inverter. Please check and maintain the following items based on the instructions below to ensure the optimal performance of the inverter. For inverters working in inferior conditions, more frequent maintenance is required. Please keep maintenance records.

 WARNING!

- Only qualified person can perform the maintenance for the inverter.
- Only spare parts and accessories authorized by SolaX can be used for maintenance.

12.4.1 Maintenance Routines

Table 12-2 Proposal of Maintenance

Item	Check Notes	Maintenance Interval
Fans	• Check if the cooling fans on the bottom of the inverter are covered by dirt or if there is abnormal sound. • Clean the cooling fans with a soft dry cloth or brush or replace it if necessary.	Every 12 months
Electrical connection	• Ensure that all cables are firmly connected. • Check the integrity of the cables, ensuring that there are no scratches on the parts touching the metallic surface. • Verify that the sealing caps on idle terminals and ports are not falling off.	Every 12 months

Item	Check Notes	Maintenance Interval
Grounding reliability	• Check whether the ground terminal and ground cable are securely connected. Use Ground Resistance Tester to test the ground resistance from inverter enclosure to PE bar in the power distribution box.	Every 12 months
Heat sink	• Check whether the heat sink is covered with foreign objects.	Every 12 months
General status of inverter	• Check if there is any damage on the inverter. • Check if there is any abnormal sound when the inverter is running.	Every 6 months

12.4.2 Replacement of Fans

When the fan is not rotating and the feedback speed of the fan is 0, the LCD screen will display **FAN1 FAULT/FAN2 FAULT/FAN3 FAULT** error. Refer to the following steps for replacement.

Step 1: Loosen the screw on the inverter with cross screwdriver, remove the outer casing of the inverter, proceed to disconnect the terminals that are connected to the fans.




Figure 12-1 Disconnecting the fans connectors

Step 2: Loosen the screws on the fan assembly and after disassembling it, replace the fans. Before replacement, make sure that the new fan can operate normally.




Figure 12-2 Replace the fan

Step 3: After replacing the fan, proceed to reassemble the components in their respective order.

12.4.3 Upgrading Firmware

! WARNING!

- Make sure that the type and format of the firmware file are correct. Do not modify the file name. Otherwise, the inverter may not work properly.
- Do not modify the folder name and file path where the firmware files are located, as this may cause the upgrade to fail.

! WARNING!

- Before upgrading, ensure that the PV input voltage is higher than 180 V (preferably on sunny day), or that the battery SOC is higher than 20%, or the battery input voltage is higher than 180 V. Failure to meet one of these conditions may result in upgrade process failure.

Upgrading preparation

- Prepare a USB drive (USB 2.0/3.0, $\leq 32 \text{ GB}$, FAT 16/32).
- Check for the current firmware version of the inverter.
- Contact our service support for the update firmware file, and save it to the USB drive.
 - » For ARM file: XXX.XXXXX.XX_XX_3P_ARM_VXXX.XX_XXXX.usb
 - » For DSP file: XXX.XXXXX.XX_XX_3P_DSP_VXXX.XX_XXXX.usb

- Check the folder name and file path:








Figure 12-3 Folder name and path

Upgrade steps


- Press and hold the **Enter** key on the inverter LCD for 5 seconds to enter the **OFF** mode.
- Remove the dongle from the Dongle port of the inverter by hand, and then insert the USB drive. The inverter will automatically display the **Upgrade Selection** interface. (For the position of Dongle port, see ["8.1.1 Terminals and Ports of Inverter"](#).)
- On the **Upgrade Selection** interface, select **ARM** or **DSP** based on the file type, and then tap **OK**.



- Select and confirm the firmware version, and then tap the **Enter** key to start updating. ARM update takes about 20 seconds, and DSP update takes about 2 minutes.



- After the upgrade is completed, the LCD screen displays **Upgrade Successful**. If the upgrades fail, the LCD screen displays **Upgrade failed**.



 CAUTION!

- If the ARM firmware upgrade fails or stops, do not unplug the U disk. Please power off the inverter and restart it. Then repeat the upgrade steps.

 CAUTION!

If the DSP firmware upgrade fails or stops, perform operations below to troubleshoot:

- Check if the DC switch is turned off. If it is off, turn it on.
- Recommended: If the DC switch is already on, check if the battery and PV parameters in **Menu>System Status** meets the upgrade requirements (The PV or battery input voltage should be larger than 180 V, or the battery SOC be higher than 20%).
- Alternatively, select **Menu > Mode Select > Manual > Forced Charge** to charge the battery. This process can help wake up the battery for DSP upgrade.

NOTICE!

- If the display screen is stuck after the upgrade, turn off the DC switch and restart. The inverter will restart and return to normal. If not, please contact us for help.

13 Decommissioning

13.1 Disassembling the Inverter

! WARNING!

- When disassembling the inverter, strictly follow the steps as below.

NOTICE!

- The AC, battery and PV connectors should be disassembled using the dedicated disassembly tool provided with the package. This is to prevent any damage to the equipment or potential injury to personnel.

Step 1: Turn off the system by System ON/OFF on LCD screen.

Step 2: Turn off the battery switch/button/breaker (if any). (See documents of battery)

Step 3: Disconnect the external AC breaker of the inverter.

Step 4: Turn the "DC" switch to "OFF" position.




Figure 13-1 Turning off the DC switch

Step 5: Wait until the LCD screen turns off.

Step 6: Disconnect the PV connectors: Insert the removal tool into the notch of PV connectors and slight pull out the connectors.




Figure 13-2 Releasing the PV connector

Step 7: Gently remove the dongle module.




Figure 13-3 Removing the dongle

NOTICE!

- This section uses a specific dongle model as an example. Please refer to your actual dongle.

Step 8: Disconnect the battery connectors: Insert the removal tool into the notch of connectors and slight pull the connectors.




Figure 13-4 Removing the Battery connector

Step 9: Disconnect the AC connector: Insert the removal tool to the slot of the AC connector to release it. Slight pull the connectors.




Figure 13-5 Removing AC connector

Step 10: Remove the swivel nut. Align the removal tool (part U or part X) with the core slot, insert it.




Figure 13-6 Remove the swivel nut

Step 11: Press down with one hand, and push the wire upwards with the other hand to disconnect the AC connector.




Figure 13-7 Disconnect the AC connector

Step 12: Disconnect the COM 1 connector and COM 2 connector: Please loosen the swivel nut of the COM connector and anti-clockwise loosen M3 screw of the communication connector by cross screwdriver. Pinch the tabs on the sides of the connector and pull the connector at the same time to remove it.

Step 13: Put the original sealing cap on the terminals and ports.

Step 14: Unscrew the grounding screw by cross head screw and remove the grounding cable.

Step 15: Unlock the anti-theft lock if you installed it. Unscrew the M5 screw on the sides of inverter and vertically lift up the inverter to dismantle the inverter.




Figure 13-8 Unscrewing the M5 screws

Step 16: Unscrew the screws for fastening the Bracket and remove the Bracket.

13.2 Packing the Inverter

- Load the inverter into the original packing material if possible.




Figure 13-9 Packing the inverter

- If the original packing material is not available, use the packing material which meets the following requirements:
 - » Suitable weight and dimensions for inverter.
 - » Easy to carry.
 - » Be capable of being closed completely.

13.3 Disposing of the Inverter

Please dispose of the inverters or accessories in accordance with the electronic waste disposal regulations applicable at the installation site.

14 Technical Data

NOTICE!

- For the X3-ULT-30K Latin America model, see its own documentation.

• INPUT PV

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Max. PV array power [Wp]	30000	30000	40000	40000	40000
Max. input PV power [W]	30000	30000	40000	40000	40000
Max. DC voltage ¹ [V]			1000		
Nominal DC operating voltage [V]			600		
No. of MPP trackers/ Strings per MPP tracker	3 (2/2/2)	2 (2/2)	2 (2/2)	2 (2/2)	3 (2/2/2)
Max. input current (input PV1/input PV2/input PV3) ² [A]	36/36/36	36/36	36/36	36/36	36/36/36
Max. short circuit current (input PV1/input PV2/input PV3) [A]	45/45/45	45/45	45/45	45/45	45/45/45
MPPT operating voltage range ³ [V]			160–950		
Start output voltage [V]			200		
Shutdown input voltage[V]			130		
Max. inverter backfeed current to the array [A]			0		

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Max. PV array power [Wp]	50000	50000	60000	20000	30000
Max. input PV power [W]	50000	50000	60000	20000	30000
Max. DC voltage ¹ [V]		1000		600	
Nominal DC operating voltage [V]		600		360	
No. of MPP trackers/ Strings per MPP tracker	3 (2/2/2)	3 (2/2/2)	3 (2/2/2)	2 (2/2)	3 (2/2/2)
Max. input current (input PV1/input PV2/input PV3) ² [A]	36/ 36/36	36/ 36/36	36/ 36/36	36/ 36	36/ 36/36
Max. short circuit current (input PV1/input PV2/input PV3) [A]	45/45/45	45/45/45	45/45/45	45/45	45/45/45
MPPT operating voltage range ³ [V]		160-950		160-560	
Start output voltage [V]			200		
Shutdown input voltage[V]			130		
Max. inverter backfeed current to the array [A]			0		

Note:

¹ The maximum input voltage is the upper limit of the DC voltage. Any higher input DC voltage would probably damage inverter.

² PV3 Only available for 15KP, 20KP, 25K, 25KW, 30K and 15K-GLV. When both strings are connected to a single MPPT, the Max. input current for a single string is 18A; When a single string is connected to one MPPT, the Max input current for a single string is 20A.

³ Input voltage exceeding the operating voltage range may triggers inverter protection.

• OUTPUT AC (On - Grid)

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Nominal AC power [VA]	15000 (14999 for AS4777)	15000 (14999 for AS4777)	19999	20000	20000
Max. apparent AC power [VA] (below +40°C)	16500 (14999 for AS4777)	16500 (14999 for AS4777)	19999	22000	22000
Rated grid voltage (AC voltage range)[V]	3P4W, 400/230, 380/220				
Current (inrush) [A]	65				
Rated grid Frequency [Hz]	50/60				
Nominal AC current [A] (230V)	21.8	21.8	29.0	29.0	29.0
Max. AC current [A](above rated current, de-rating is acceptable)(230V)	24.0 (21.8 for AS4777)	24.0 (21.8 for AS4777)	29.0	31.9	31.9
Displacement power factor	1 (-0.8–0.8)				
Total harmonic distortion (THDi, rated power)	< 3%				
Maximum out fault current [A]	100	100	140	140	140
Maximum output overcurrent protection [A]	147	147	163	163	163

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Nominal AC power [VA]	25000 (24900 for VDE4105)	25000	30000 (29999 for AS4777, 29900 for VDE4105)	9999	15000
Max. apparent AC power [VA] (below +40°C)	27500 (24900 for VDE4105)	25000	30000 (29999 for AS4777, 29900 for VDE4105)	9999	15000
Rated grid voltage (AC voltage range)[V]	3P4W, 400/230, 380/220			3P3W, 230/133, 220/127	
Current (inrush) [A]	65				
Rated grid Frequency [Hz]	50/60				
Nominal AC current [A](230V)	36.3	36.2	43.5	25.2	37.7
Max. AC current [A](above rated current, de-rating is acceptable)(230V)	39.9 (36.3 for VDE4105)	36.2	43.5	25.2	37.7

Technical Data

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Displacement power factor	1 (-0.8 to 0.8)				
Total harmonic distortion (THDi, rated power)	< 3%				
Maximum out fault current [A]	155	155	175	100	155
Maximum output overcurrent protection [A]	172	172	181	147	172

• INPUT AC

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Max. AC input apparent power [VA]	34500@230 a.c. V	34500@230 a.c. V	34500@230 a.c. V	34500@230 a.c. V	34500@230 a.c. V
Max. AC current [A]	50	50	50	50	50
Rated grid voltage (AC voltage range) [V]	3P4W, 400/230, 380/220				
Rated grid Frequency [Hz]	50/60				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Max. AC input apparent power [VA]	34500@230 a.c. V	34500@230 a.c. V	34500@230 a.c. V	19950@133 a.c. V	19950@133 a.c. V
Max. AC current [A]	50	50	50	50	50
Rated grid voltage (AC voltage range) [V]	3P4W, 400/230, 380/220			3P3W, 230/133, 220/127	
Rated grid Frequency [Hz]	50/60				

• BATTERY

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Battery type	Lithium - ion				
Battery voltage range ⁴ [V]	120–800				
Max. charge/discharge power [kW]	15/15	15/15	20/20	20/20	20/20
Max. charge/discharge current [A]	60 (30 × 2)				
Number of connectible batteries	2				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Battery type	Lithium - ion				
Battery voltage range ⁴ [V]	120–800			120–550	
Max. charge/discharge power [kW]	24/24	24/24	24/24	10/10	16.5/16.5
Max. charge/discharge current [A]	60 (30 × 2)				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Number of connectible batteries	2				

⁴ Compatible with a minimum of 3 units of HS Series batteries, but if the total voltage of the 3 batteries is less than 127V and there is no PV input, the system will not able to start. When the voltage is below 180V, the inverter will limit the battery current to less than 20A.

• EPS OUTPUT (WITH BATTERY)

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
EPS peak power [VA]	2 time of rated power, 10 s				
EPS rated power [VA]	15000	15000	19999	20000	20000
EPS rated voltage [V], Frequency [Hz]	400/230, 50/60				
EPS rated current [A] [220V]	22.8	22.8	30.4	30.4	30.4
EPS rated current [A] [230V]	21.8	21.8	29.0	29.0	29.0
Switchover time [ms]	< 10				
Total harmonic distortion (THD, linear Load)	< 3%				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
EPS peak power [VA]	2 time of rated power, 10 s				
EPS rated power [VA]	25000	25000	30000	10000	15000
EPS rated voltage [V], Frequency [Hz]	400/230, 50/60			230/133, 50/60	
EPS rated current [A] [220V]	37.9	37.9	45.5	26.3	39.5
EPS rated current [A] [230V]	36.3	36.3	43.5	25.2	37.7
Switchover time [ms]	< 10				
Total harmonic distortion (THD, linear Load)	< 3%				

• EFFICIENCY

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
MPPT efficiency	99.9%				
Max. efficiency	98.00%				
European efficiency	97.7%				
Rated Battery charge efficiency	98.5%				
Rated Battery discharge efficiency	97.0%				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
MPPT efficiency			99.9%		
Max. efficiency			98.00%		
European efficiency			97.7%		
Rated Battery charge efficiency			98.5%		
Rated Battery discharge efficiency			97.0%		

• POWER CONSUMPTION

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Internal consumption (night) [W]			< 5		

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Internal consumption (night) [W]			< 5		

• PROTECTION

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Anti-islanding protection			Yes		
DC reverse polarity protection			Yes		
Insulation monitoring			Yes		
Residual current monitoring			Yes		
AC overcurrent protection			Yes		
AC short-circuit protection			Yes		
AC overvoltage protection			Yes		
Over-heat protection			Yes		
AFCI	F-I-AFPE-1-2-3	F-I-AFPE-1-2-2	F-I-AFPE-1-2-2	F-I-AFPE-1-2-2	F-I-AFPE-1-2-3
Battery reverse charging from grid			Yes		
Surge protection			Type II, DC and AC		

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Anti-islanding protection			Yes		
DC reverse polarity protection			Yes		
Insulation monitoring			Yes		
Residual current monitoring			Yes		
AC overcurrent protection			Yes		
AC short-circuit protection			Yes		
AC overvoltage protection			Yes		
Over-heat protection			Yes		
AFCI	F-I-AFPE-1-2-3	F-I-AFPE-1-2-3	F-I-AFPE-1-2-3	F-I-AFPE-1-2-2	F-I-AFPE-1-2-3
Battery reverse charging from grid			Yes		
Surge protection			Type II, DC and AC		

• ENVIRONMENT LIMIT

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Ingress protection			IP66		
Protective class			Class I		
Pollution degree			PD3		
Operating temperature range [°C]		-35 to +60 (Derating above +45)			
Humidity [%]			0 – 100		
Altitude [m]			< 3000		
Storage temperature [°C]			-40 – +70		
Noise emission (typical) [dB]			< 45		
Over voltage category			DC: II ; Main: III		

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Ingress protection			IP66		
Protective class			Class I		
Pollution degree			PD3		
Operating temperature range [°C]	-35 to 60 (Derating above +45)			-35 to 60	
Humidity [%]			0–100		
Altitude [m]			< 3000		
Storage temperature [°C]			-40 to +70		
Noise emission (typical) [dB]			< 45		
Over voltage category			DC: II ; Main: III		

Technical Data

• GENERAL

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Dimensions (W*H*D) [mm]	696 * 526 * 240				
Weight [kg]	47.5±1.5	46±1.5	46±1.5	46±1.5	47.5±1.5
Cooling concept	Smart cooling				
Topology	Transformerless				
Communication	Modbus (RS485), Meter (RS485), DI × 2, DO × 1				
LCD display	Yes				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Dimensions (W*H*D) [mm]	696 × 526 × 240				
Weight [kg]	48.5±1.5	48.5±1.5	48.5±1.5	46±1.5	46±1.5
Cooling concept	Smart cooling				
Topology	Transformerless				
Communication	Modbus (RS485), Meter (RS485), DI * 2, DO * 1				
LCD display	Yes				

• STANDARD

Model	X3-ULT-15KP	X3-ULT-15K	X3-ULT-19.9K	X3-ULT-20K	X3-ULT-20KP
Safety	EN/IEC 62109 -1/-2				
EMC	EN61000-6-1/2/3/4; EN61000-3-11/12; EN 5011; IEC 62920				
Certification	VDE4105/G99/AS4777/EN50549/CEI 0-21/IEC61727/PEA/MEA/NRS-097-2-1/RD1699/TOR				

Model	X3-ULT-25K	X3-ULT-25KW	X3-ULT-30K	X3-ULT-10K-GLV	X3-ULT-15K-GLV
Safety	EN/IEC 62109 -1/-2				
EMC	EN61000-6-1/2/3/4; EN61000-3-11/12; EN 5011; IEC 62920				
Certification	VDE4105/G99/AS4777/EN50549/CEI 0-21/IEC61727/PEA/MEA/NRS-097-2-1/RD1699/TOR				

* The specific gross weight is subject to the actual situation of the whole machine.

15 Appendix

15.1 Installation Video

A QR code for the installation video is on the front of the inverter. Simply scan it with your phone (iOS or Android) to watch the video.

NOTICE!

The installation video is provided for reference only, and might be updated as needed. Please install the inverter following the installation manual and local regulations.



Figure 15-1 Scanning to view the installation video

15.2 Application of Generator

15.2.1 Introduction of Generator Application

In certain regions where utility power is unstable, the use of generators becomes necessary to ensure uninterrupted operation of loads. The characteristic of this system is its ability to seamlessly switch to generators combined with an energy storage system, forming a new power supply configuration in the absence of utility power.

A diesel generator is employed to replicate grid-like functionality, while a hybrid inverter converts solar energy into usable electric energy.

15.2.2 Notice for Generator Application

- Note 1: The generator should be equipped with an ATS, enabling it to start automatically in the event of a power outage.
- Note 2: The rated output power of the generator should be greater than the sum of the load power and the battery charging power. If there are two inverters in parallel, the rated output power of the generator should be greater than the sum of the load power and the battery charging power of the two inverters.
- Note 3: If the rated output power of the generator is small and cannot meet the requirements of Note 2, the setting value of **MaxChargePower** can be changed in the **Menu>Setting>Advance Setting>ExternalGen** to ensure that the generator power can meet the load and battery charging use at the same time.
- Note 4: The EPS load power cannot be greater than the battery discharge power to prevent the battery power from being unable to meet the EPS load after the generator shuts down and the inverter will report **Overload fault**. If two inverters are paralleled, the EPS load power shall be doubled.

15.2.3 ATS Control Mode

In this operating mode, the generator functions as a substitute for the grid. There is no communication between the generator and the inverter, which means no wiring modifications are required (however, the inverter is also unable to control the generator). The ATS that accompanies the generator will determine whether the generator should be turned on or off based on the status of the grid.

Wiring connection diagram




Figure 15-1 ATS control wiring diagram

Inverter settings for ATS control mode

- a. Select **Menu>Setting>Advance Setting>ExternalGen>ATS Control**.

====ExternalGen====
>Function Control
ATS Control

- b. Set the relative parameters as below in accordance with actual needs.

- » **MaxChargePower**: Maximum battery charging power from generator. (0-30000 W, 5000 W by default)

====ExternalGen====
>MaxChargePower
XXXXW

- » **Char&Disc Period**: Including **Forced Charge Period** and **Allowed Disc Period**. Two periods can be set. These period settings are associated with the same settings under **Work Mode** for no need to jump to work mode page to set the working period when using generator mode.

====ExternalGen====
>Forced Charge Period
Start Time
00:00

====ExternalGen====
>Allowed Disc Period
Start Time
00:00

====ExternalGen====
>Forced Charge Period
End Time
00:00

====ExternalGen====
>Allowed Disc Period
End Time
00:00

- » **Charge from Gen and Charge battery to**: The SOC which allows the system charging from generator. (10-100%, 10% by default)
- c. Select **Menu>Setting>Advance Setting>Meter/CT Setting**.
- d. Set the address and direction of Meter 2: You can check the connection status in **Meter/CT Check**.



15.2.4 Dry Contact Mode

In this operating mode, users can intelligently control the system by establishing a dry contact connection between the inverter and the generator. It allows for adjustments to multiple settings so that the system can meet the requirements of different scenarios.

Wiring connection diagram




Figure 15-2 Dry contact wiring diagram

Inverter connection for dry contact mode

- Connection port-DIO port




Figure 15-3 Connection port for generator

- Connection pins-Pin 1 and Pin 2

Table 15-1 Connection pins for generator

Application	Generator dry contact output		System switch dry contact input		Reserved		
Pin	1	2	3	4	5	6	7
Assignment	DO_1	DO_2	DI_1+	DI_1-	DI_2+	DI_2-	GND_COM

- Connection steps: Please refer to ["8.7.4 DIO Communication Connection"](#) for specific wire making and connection.
- Inverter settings for dry contact mode
- a. Select **Menu>Setting>Advance Setting>ExternalGen>Dry Contact.**

```
=====ExternalGen=====
>Function Control
  Dry Contact
```

- b. Set the relative parameters in accordance with actual needs.

- » **MaxChargePower:** Maximum battery charging power from generator. (0-30000 W, 5000W by default).

```
=====ExternalGen=====
>MaxChargePower
  5000W
```

- » **Start Gen Method:** **Reference SOC** and **Immediately** can be selected.
Reference SOC: Turn on/off generator according to the set **Switch on/off SOC**. **Immediately:** Turn on /off the generator when grid status changed.

```
=====ExternalGen=====
>Start Gen Method
  Reference soc
```

```
=====ExternalGen=====
>Start Gen Method
  Immediately
```

- » **Switch on/off SOC:** the option is activated when you select **Reference SOC** for **Start Gen Method**. Inverter will turn on the generator when the battery reaches the set **Switch on SOC** and turn it off when the battery reaches the set **Switch off SOC**.

```
=====ExternalGen=====
>Switch on SoC
  0%
```

```
=====ExternalGen=====
>Switch off SoC
  0%
```

- » **MaxRunTime:** Maximum operating time of generator. (30 Min by default)

```
=====ExternalGen=====
>MaxRunTime
  30Min
```

- » **MinRestTime:** Minimum time interval for two consecutive starts to avoid frequent generator on and off.

```
=====ExternalGen=====
>MaxRestTime
0Min
```

- » **Char&Disc Period:** Including **Forced Charge Period** and **Allowed Disc Period**. Two periods can be set. These period settings are associated with the same settings under **Work Mode** for no need to jump to work mode page to set the working period when using generator mode.

```
=====ExternalGen=====
>Forced Charge Period
Start Time
00:00
```

```
=====ExternalGen=====
>Allowed Disc Period
Start Time
00:00
```

```
=====ExternalGen=====
>Forced Charge Period
End Time
00:00
```

```
=====ExternalGen=====
>Allowed Disc Period
End Time
00:00
```

- » **Allow Work:** Allowed time period for generator operating. You can set the start time and end time.

```
=====ExternalGen=====
>Allow Work
Start Time
00:00
```

```
=====ExternalGen=====
>Allow Work
End Time
00:00
```

- » **Charge from Gen and Charge battery to:** The SOC which allows the system charging from generator. (10-100 W from generator, 10% by default)

```
=====ExternalGen=====
Charge from GEN
> Enable <
```



```
=====ExternalGen=====
>Charge battery to
10%
```

- Select **Menu>Setting>Advance Setting>Meter/CT Setting**.
- Set the address and direction of Meter 2: You can check the connection status in **Meter/CT Check**.

```
=====CT/MeterSetting=====
>Select
Meter
```



```
=====CT/MeterSetting=====
>Select
Enable
```



```
=====CT/MeterSetting=====
>Meter 2 Addr
2
```



```
=====CT/MeterSetting=====
>Meter 2 Direction
Positive
```

15.3 Application of Adapter Box G2

15.3.1 Introduction of Adapter Box G2 Application

With the SolaX Adapter Box G2, users can effectively utilize solar energy by commanding it to power their heat pump using settings available on the SolaX inverter and SolaXCloud. This intelligent integration allows for optimized solar self-consumption and ultimately helps in reducing electricity bills.

Wiring connection diagram




Figure 15-4 Adapter Box G2 wiring diagram

The inverter communicates with Adapter Box G2 via RS485. In case of excess power, the Adapter Box G2 can utilize it to heat the pump through the connection of dry contacts, SG Ready, or Analog output between the Adapter Box G2 and the heat pump. To power the Adapter Box G2, an external power adapter is required as the inverter itself cannot supply power to the Adapter Box G2.

15.3.2 Communication Connection with Inverter

- Connection port-RS485 port




Figure 15-5 Connection port for Adapter Box G2

- Connection pins

Table 15-2 Pin-to-pin connection for inverter and Adapter Box G2

RS485 port of inverter		RS485_INV port of Adapter Box G2	
Pin	Pin assignment	Pin	Pin assignment
3/4	Parallel_485AA	4	RS485-A
5/6	Parallel_485BB	5	RS485-B

- Connection steps-Please refer to "8.6.4 RS485 Communication Connection" for specific wire making and connection




Figure 15-6 Connecting to Adapter Box G2


NOTICE!

- For details on connecting the power adapter and the heat pump to the Adapter Box G2, refer to the documentation of Adapter Box G2.

Settings for Adapter Box G2

Setting path: **Menu>Setting>Advance Setting>Internal485**


- a. Select **Menu>Setting>Advance Setting>Internal485**;
- b. Select the **Heatpump Ctrl** and set the **Baud Rate** and corresponding Address. The default **Baud Rate** is 9600.



NOTICE!

- When two equipments need to be connected at the same time, the Baud rate and address of the two equipments shall be set to the same.

- c. Check the connection status.



NOTICE!

- For specific wiring and setting procedures of Adapter Box G2, see *Adapter Box G2 User Manual*.

15.4 Application of EV Charger

15.4.1 Introduction of EV-Charger Application

The EV charger is intended for charging electric vehicles. It should be installed in a fixed location and connected to the AC supply. The EV charger can communicate with other devices or systems (inverter, meter, CT, third-party charger management platform, etc.) to realize intelligent control of charging process.

15.4.2 Wiring Connection Diagram

- Connecting to Smart EV Charger




Figure 15-7 Smart EV Charger wiring diagram

- Connecting to Smart EV Charger G2




Figure 15-8 Smart EV Charger G2 wiring diagram

15.4.3 Communication Connection with Inverter

- Connection port-RS485 port




Figure 15-9 Connection port for EV-Charger

- Connection pins

Table 15-3 Pin-to-pin connection for inverter and EV-Charger

RS485 port of inverter		COM port of EV-Charger	
Pin	Pin assignment	Pin	Pin assignment
3/4	Parallel_485AA	4	A1
5/6	Parallel_485BB	5	B1

- Connection steps-Please refer to "[8.6.4 RS485 Communication Connection](#)" for specific wire making and connection.




Figure 15-10 Connecting to EV-Charger

15.4.4 Setting for EV Charger

- Select **Menu>Setting>Advance Setting>Internal485**;
- Select the **EV Charger** and set the **Baud Rate** and corresponding Address. The default **Baud Rate** is 9600.

```
====Internal485=====
```

```
>Function Control
  EV Charger
```



```
====Internal485=====
```

```
>Baud Rate
  9600
```



```
====Internal485=====
```

```
>EV Charger Addr:
  70
```

NOTICE!

- When two equipments need to be connected at the same time, the Baud rate and address of the two equipments shall be set to the same.

- Check the connection status.

```
====Internal485=====
```

```
>EV Charger COM STAT
  Connected
```

- You can enable **Battery Charge EVC** to allow the battery to discharge energy to EV-Charger through setting path: **Menu>Setting>Advance Setting>Battery Charge EVC**.

```
===Battery charge EVC===
```

```
>Function Control
  Enable
```

NOTICE!


- For specific wiring and setting procedures of the EV charger, see the documentation of the Smart EV Charger or the Smart EV Charger G2 product.

15.5 Application of DataHub

15.5.1 Introduction of DataHub Application

SolaX DataHub can be connected to inverters through RS485 to control the output power of the entire power station according to on-site requirements. Besides, it can work with SolaXCloud to monitor all inverters, allowing for real-time data display and device management. In the entire system, a maximum of 10 X3-ULTRA series inverters can be connected to the DataHub.

15.5.2 Wiring Connection Diagram



15.5.3 Communication Connection with Inverter

- Connection port-RS485 port




Figure 15-12 Connection port for DataHub

- Connection pins

Table 15-4 Pin-to-pin connection for inverter and DataHub

RS485 port of inverter		RS485-1 port of DataHub	
Pin	Pin assignment	Pin	Pin assignment
3/4	Parallel_485AA	/	A+
5/6	Parallel_485BB	/	B-

- Connection steps-Please refer to "8.6.4 RS485 Communication Connection" for specific wire making and connection.





Figure 15-13 Connecting to DataHub

15.5.4 Settings for DataHub

- a. Select **Menu>Setting>Advance Setting>Internal485**;
- b. Select the **Smart Ctrl** and set the **Baud Rate** and corresponding Address.



NOTICE!

- The Baud rate, communication protocol and verification method of the inverters connected to the same RS485 port of DataHub must be consistent, and the communication addresses of the inverters must be consecutive and not repeated.

NOTICE!

- For specific wiring and setting procedures of DataHub, see *DataHub 1000 User Manual*.

15.6 Micro-grid Application

15.6.1 Introduction of Micro-grid Application

Due to Islanding Effect, on-grid inverter is unable to work during off-grid. This characteristic makes user losing the on-grid inverter PV energy when off-grid. Micro-grid is the function that making hybrid inverter simulate the grid to active on-grid inverter during off-grid by connecting on-grid inverter to hybrid inverter's EPS port.

15.6.2 Wiring Connection Diagram




Figure 15-14 Micro-grid wiring connection

15.6.3 Working Modes

Grid-on

- When PV is sufficient, the hybrid and on-grid inverters power the common and EPS loads together. When there is surplus energy on the on-grid inverter, it will also charge the battery.
- When PV is insufficient, the hybrid, on-grid inverter and grid power all the loads.




Figure 15-15 Power flowing when grid on and PV sufficient

Grid-off

In this case, the hybrid inverter will simulate the grid so as to make the on-grid inverter work. Hybrid and on-grid inverter will power the EPS loads together. If there is surplus energy, it will charge the battery.




Figure 15-16 Power flowing when grid off

NOTICE!

- In EPS mode, due to limited battery charging power, the hybrid inverter will increase the EPS output frequency to restrict and shut down the on-grid inverter, ensuring the stable operation of the entire system. In this period, the on-grid inverter may report a **Grid FreqFault** which is a normal phenomenon.

Notice for micro-grid application

- Any brand of on-grid inverter that supports "frequency adaptation".
- On-grid inverter output power $\leq$ Max hybrid inverter EPS output power.
- On-grid inverter output power $\leq$ Max battery charging power.

NOTICE!

- Since the X3-ULTRA series inverter is unable to control the output power of on-grid inverter in grid connection mode, X3-ULTRA series inverter can not achieve zero export when loads power + battery charging power < on-grid inverter output power.

15.6.4 Cable Connection (Hybrid Inverter)

Please refer to "8.3 AC Connection" for Grid and EPS connection on X3-ULTRA series inverter.

15.6.5 Cable Connection (On-grid Inverter)

Please connect the AC cable of on-grid inverter to the EPS port of X3-ULTRA series inverter. Please refer to the user manual of specific on-grid inverter.

15.6.6 Cable Connection (Meter)

To detect and monitor the power data generated from the on-grid inverter, install a meter on the on-grid inverter side. Otherwise, the relevant power data of on-grid inverter can not be monitored. The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire.




Figure 15-17 Connection diagram of Meter on EPS port

NOTICE!

- If a splitter adapter for RJ45 terminal is used, it should be placed in a waterproof enclosure.

- Pin assignment

Table 15-5 Pin assignment for meter and CT


Application	For CT1			For meter		For CT2		
Pin	1	2	3	4	5	6	7	8
Assignment	CT_ R1_ CON	CT_ S1_ CON	CT_ T1_ CON	METER _485A	METER _485B	CT_ T2_ CON	CT_ S2_ CON	CT_ R2_ CON

- Meter/CT connection steps-Please refer to "8.7.2 Meter/CT Connection" and meter/CT user manual for specific connection steps.


- Setting on the LCD

For meter 1 and meter 2 solution (Meter 1 for grid connection, Meter 2 for EPS)

- a. Select **Menu>Setting>Advance Setting>Meter/CT Setting**.
- b. Set the address and direction of Meter 1: You can check the connection status in **Meter/CT Check**.




- c. Set the address and direction of Meter 2. You can check the connection status in **Meter/CT Check**.




- d. After connection succeeded, check the feed-in power of Meter 1 in the path of **Menu>System Status>Meter/CT** and check the output power (**Output Today** and **Output Total**) of Meter 2 in the path of **Menu>History Data>E_USERDEF**.

For CT and meter 2 solution (CT for grid connection, Meter 2 for EPS)

- a. Select **Menu>Setting>Advance Setting>Meter/CT Setting**.
- b. Select and enable the CT function, select the CT. You can check the connection status in **Meter/CT Check**.



- c. Set the address and direction of Meter 2. You can check the connection status in **Meter/CT Check**.



- d. After connection succeeded, check the feed-in power of Meter 1 in the path of **Menu>System Status>Meter/CT** and check the output power (**Output Today** and **Output Total**) of Meter 2 in the path of **Menu>History Data>E_USERDEF**.

15.7 Application of Parallel Function

15.7.1 Introduction of Parallel Application

The series inverters support parallel operation in both Grid and EPS modes. They can be configured with the X3-EPS Parallel Box G2 or operated independently. Without the X3-EPS Parallel Box G2, the parallel system supports up to 3 units; with the box, up to 10 units are supported. Details are as follows:

Table 15-6 Maximum number of inverter paralleled

Application	X3-ULT-15KP X3-ULT-15K	X3-ULT-19.9K X3-ULT-20K X3-ULT-20KP	X3-ULT-25K X3-ULT- 25KW	X3-ULT- 30K	X3-ULT-10K- GLV X3-ULT-15K- GLV
With X3- PBOX- 150kW-G2.1	10	7	6	5	/
With X3- PBOX- 300kW-G2.1		10			/
Without Parallel Box			3		

NOTICE!

- The X3-EPS Parallel Box G2 is not supported by GLV models. Do not attempt to use it with GLV units, as this may cause system malfunction or damage.
- The actual number of paralleled units may vary depending on the device.

15.7.2 Notice for Parallel Application

- All inverters should be of the same software version.
- For optimal efficiency, it is recommended that all inverters have the same model, and are connected to batteries of the same model and quantity.
- In parallel system, there are three status: **Free**, **Slave** and **Master**.

Table 15-7 Three status

Status	Description
Free	Only if no one inverter is set as a Master , all inverters are in Free mode in the system.
Slave	Once one inverter is set as a Master , all other inverters will enter Slave mode automatically. Slave mode can not be changed from other modes by LCD setting.
Master	When one inverter is set as a Master , this inverter enters Master mode. Master mode can be changed to Free mode.

- Master inverter has an absolute lead in the parallel system to control all slave inverter's energy management and dispatch control. Once master inverter has some error and stop working, all slave inverter will be stop simultaneously. But master inverter is independent of all slave inverter to work and will not be affected by slave inverter's fault.
- Overall system will be running according to master inverter's setting parameters, and most setting parameters of slave inverter will be kept but not be cancelled.
- Once slave inverter exits from the system and be running as an independent unit (the network cable is disconnected simultaneously), its all setting will be re-activated.
- The parallel system is extremely complex and requires a large number of cables to be connected. Therefore, the cables must be connected in the correct wire sequence. Otherwise, any small mistake can lead to system failure.
- The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire.

NOTICE!

- The X3-EPS Parallel Box G2 is not supported by GLV models.

Parallel connection diagram




Figure 15-18 Parallel connection diagram with X3-EPS Parallel Box G2




Figure 15-19 Parallel connection diagram without X3-EPS Parallel Box G2

15.7.3 System Wiring Procedure

- Use five-core copper cable to connect Master-Slave inverter.
- Grid port of Master and Slave inverter: L1 connects to L1, L2 connects to L2, L3 connects to L3 and N connects to N (The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire).
- EPS terminal of Master and Slave inverter: L1 connects to L1, L2 connects to L2, L3 connects to L3 and N connects to N (The X3-ULT-10K-GLV and X3-ULT-15K-GLV do not connect to the N wire).
- All PE cable connects to the same E-BAR nearby.




Figure 15-20 Power cable connection without X3-EPS Parallel Box G2

Communication cable wiring-COM1 port and COM2 port

- With X3-EPS Parallel Box G2.
 - a. Use standard network cables for Master-Slave inverter connection.
 - b. Master inverter Parallel-1 connects to the COM port of X3-EPS Parallel Box G2.
 - c. Master inverter Parallel-2 connects to Slave 1 inverter Parallel-1;
 - d. Slave 1 Parallel-2 connects to Slave 2 Parallel-1; other inverters are connected in such way.
 - e. Meter connects to Meter/CT port of the Master inverter. Please refer to "[8.7.2 Meter/CT Connection](#)".




Figure 15-21 Communication connection with X3-EPS Parallel Box G2

NOTICE!

- The X3-EPS Parallel Box G2 is not supported by GLV models.

- Without X3-EPS Parallel Box G2.
 - » Use standard network cables for Master-Slave inverter connection.
 - » Master inverter Parallel-2 connects to Slave 1 inverter Parallel-1.
 - » Slave 1 inverter Parallel-2 connects to Slave 2 inverter Parallel-1.
 - » Meter connects to Meter/CT port of the master inverter. Please refer to ["8.7.2 Meter/CT Connection"](#).




Figure 15-22 Communication connection without X3-EPS Parallel Box G2

NOTICE!

- Please refer to the documentation of X3-EPS Parallel Box G2 for parallel connection on X3-EPS Parallel Box G2 side.
- For inverter setup, refer to ["8.3 AC Connection"](#) and ["8.6.2 Parallel Communication Connection"](#).

Meter/CT setting

Setting path: **Menu>Setting>Advance Setting>Meter/CT Setting**. For details, see ["Meter/CT Setting"](#).

Parallel setting

Setting path: **Menu>Setting>Advance Setting>Parallel Setting**.

How to build the parallel connection

- Turn on the power of the entire system, find the inverter which needs to be set as Master and connect the meter to Master inverter, enter the setting page of the Master inverter LCD screen, select the **Parallel Setting**, and select **Master**; then enter the **Resistance Switch** and set it to **ON**;



- b. Find the last slave in the parallel system and enter the setting page of the inverter LCD screen and set the **Resistance switch** to **ON**.

```
====Parallel Setting====
>Resistance switch
      ON
```

How to remove the parallel connection

- a. Find the inverter which needs to be set as Free. Select the **Parallel Settings** and select **Free** for the inverter

```
====Parallel Setting====
>Setting
      Free
```

- b. Disconnect all the network cables on the Parallel-1 and Parallel-2 port.

NOTICE!

- If a slave inverter is set to **Free** mode but not disconnect the network cable, this inverter will return to **Slave** mode automatically.
- If a slave inverter is disconnected with other inverter but not be set to **Free** mode, this inverter will stop working and report a **ParallelFault**..

External ATS setting

Setting path: **Menu>Setting>Advance Setting>External ATS**.

When the X3-EPS Parallel Box G2 is connected in the parallel system, enable the function.

```
=====External ATS=====
Function Control
> Enable <
```

NOTICE!

- If the output power does not reach the expected level, you can check whether the output power is set reasonably by following the path: "**Menu> Setting > Advance Setting > Export Control**".
- When the inverter is connected without X3-EPS Parallel Box G2, the External ATS must be set to **disable** or it will affect its off-grid switching.


Parallel display

Displaying path: **Menu>Parallel Status**

NOTICE!

- Once inverter enters parallel system, the **Today** yield will be replaced by **Parallel**.

In **Parallel Status** interface, the whole system power and individual slave inverter power can be obtained in **Parallel Status** interface of master inverter. The number displayed in the **Parallel Status** interface refers to the total number of online inverters, for example two inverters in parallel in the below figure.



15.8 Cable Cover

This product has a matching independently sold cable cover, which can be purchased from SolaX if required.

15.8.1 Appearance




Figure 15-23 Appearance with cable cover (Unit: mm)

15.8.2 Scope of Delivery




Table 15-1 Packing list

Item	Description	Quantity
A	Cable cover	1 pcs
B	Wi-Fi connecting cable	1 pcs
C	Wi-Fi stand	1 pcs

15.8.3 Additionally Required Materials

Table 15-2 Additionally required materials

Required Material	Type	Quantity	Remark
(Optional) Anti-theft lock	< Ø7 mm	2 PCS	Install on both sides of the cable cover to prevent it from opening.

15.8.4 Installation Steps

Cable cover installation

Step 1: Remove the screws on both sides of the inverter, then align the cable cover with the holes, and finally tighten the screws.




Figure 15-24 Installing the cable cover

Step 2: Remove the protective coil from the selected port for utilization.




Figure 15-25 Removing the protective coil

Step 3: Unlock the draw latches on both sides of the cable cover, and then remove the front panel.




Figure 15-26 Removing the front panel

PE cable connection

For the process of making the PE cable, please refer to "[PE connection procedures](#)".

Step 1: Connect the PE cable to the inverter's ground connection point through the wiring hole in the cable cover shown. (Torque: 5.0 ± 0.5 N·m)




Figure 15-27 Connecting the PE cable

AC Connection

For the process of making the AC cable, please refer to "[Wiring procedures for AC connection](#)".

- Step 1:** Loosen the screws from the Grid wiring hole and the EPS wiring hole on the cable cover.




Figure 15-28 Loosening the screws from cable cover

- Step 2:** Thread the five-core cable through the corresponding Grid and EPS wiring holes, and then, referring to "[Wiring procedures for AC connection](#)", install the AC connector.




Figure 15-29 Threading the cable

- Step 3:** Remove the AC caps and plug the assembled AC connectors into Grid port and EPS port correspondingly. Screw the removed screws. (Torque: 1.6 ± 0.1 N·m)




Figure 15-30 Installing the AC connector

PV connection

For the process of making the PE cable, please refer to "[Wiring procedures for PV connection](#)".

Step 1: Remove the PV terminals caps, then thread the prepared PV cable through the cable cover's wiring holes, and connect the assembled PV connectors to the corresponding terminals until an audible 'Click' is heard.




Figure 15-31 Connecting the PV cable

Battery power cable connection

For the process of making the battery power cable, please refer to "[Wiring procedures for battery connection](#)".

Step 1: Remove the BAT terminals caps, then thread the prepared battery power cable through the cable cover's wiring holes, and connect the assembled battery connectors to the corresponding terminals until an audible 'Click' is heard.




Figure 15-32 Connecting the battery power cable

Communication connection

Step 1: Before connecting the cable to the connector, first thread the cable through the wiring hole on the cable cover. For other operations, refer to "[8.6 COM 1 Communication Connection](#)" and "[8.7 COM 2 Communication Connection](#)".




Figure 15-33 Connecting to COM port

Monitoring connection (Wi-Fi mode)

This section uses a specific dongle model as an example. Please refer to your actual dongle. For dongle installation, see its documentation.

Step 1: Route the Wi-Fi connecting cable.

- a. Plug one end of the Wi-Fi connecting cable into the **Dongle** terminal.
- b. Remove the pre-installed plug from the cable entry hole on the right side of the enclosure.
- c. Pull the Wi-Fi cable out of the hole.
- d. Loosen the screws on the side of the inverter.




Figure 15-34 Installing the Wi-Fi connecting cable

Step 2: Loosen the screws on the Wi-Fi connecting cable, slide it into the Wi-Fi stand, tighten the screws, and mount them to the right side of the inverter using screws.




Figure 15-35 Installing the Wi-Fi stand

Step 3: Plug the dongle into the Wi-Fi connecting cable.




Figure 15-36 Installing the dongle

Monitoring connection (LAN mode)

This section uses a specific dongle model as an example. Please refer to your actual dongle. For dongle installation, see its documentation.

Step 1: Insert the assembled dongle into the **DONGLE** port and thread the other end through the wiring hole to the router.




Figure 15-37 Installing the dongle

Front panel installation

- Step 1:** After the installation is complete, conduct the pre-commissioning inspection according to "9.1 Checking before Power-on".
- Step 2:** Refer to "9.2 Powering on the System" to power on the inverter.
- Step 3:** After the inverter is operating normally, install the front panel.




Figure 15-38 Installing the front panel

- Step 4:** (Optional) For safety reasons, install the anti-theft locks on both sides of the cable cover. Please note that the locks are not in the scope of delivery. Prepare them suitable for the lock hole diameter ($\varnothing < 7$ mm) by yourself. Keep the key to the lock in a safe place.




Figure 15-39 Installing the locks



SolaX Power Network Technology (Zhejiang) Co., Ltd.

Add.: No. 278, Shizhu Road, Chengnan Sub district, Tonglu County,
Hangzhou, Zhejiang, China
E-mail: info@solaxpower.com